

FINISHING TOUCH®


FLAWLESS®



FACIAL HAIR REMOVER

REPLACEMENT HEADS

Go to www.FlawlessHeads.com
to purchase extra replacement heads



- Get started by twisting the used rotating hair removal head counter-clockwise and lift off.
- Take new head and place back on the unit by lining up the “groove” indicators on the cap with those on the unit and twisting clockwise.

For optimal results it is recommended that you replace your Flawless head every 3-4 months, or when it no longer provides the desired results. The head may need to be replaced sooner if the Flawless loses performance or if the head becomes chipped or damaged in any way.

Go to www.flawlessheads.com for special replacement head offer.

Distributed by:
idea
village®

FTFLAWINSERT111317MW