


此页不出菲林, 仅作电子文档说明
材料: 双铜纸105g
大小: 单页148*210mm
彩色印刷, 内容清晰
版本号V1.0



USER'S MANUAL

Car Fridge

EP24413/EP24414US/EP24414AU

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.




Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.


Operating Description

A EP24414US/EP24414AU

- Press button to switch ON/OFF.
- Press **+** or **-** for temperature setting.
- Press setting and choose ECO(Energy-saving) or MAX(Fast cooling). Factory setting is MAX.
- Long press for three seconds. When H flashes on the screen, select three battery protection modes H(High), M(Middle) and L(Low) by pressing setting button again. Factory setting is H.




B EP24413



- Long press button for three seconds to switch ON/OFF.
- Press **+** or **-** for temperature setting. The temperature of the left carton must not be lower than that of the right carton
- Press setting and choose ECO(Energy-saving) or MAX(Fast cooling). Factory setting is MAX.
- Long press for three seconds. When H flashes on the screen, select three battery protection modes H(High), M(Middle) and L(Low) by pressing setting button again. Factory setting is H.
- APP type: Press setting button after AP is displayed on the panel when connecting with APP by bluetooth
- Icons under the screen: Left Zone: Right Zone
- Press upper **+** **-** at the same time for three seconds to switch on/off the left zone.
- Lower screen is off after removing the divider (two zones merged) and temperature control can be done by upper screen only.

Detachable to adjust inner space




Product Specification:


Model no	EP34414US/EP24414AU
Capacity	55L
Power supply	DC 12V/24V AC 100-240V (with adaptor) 50-60Hz
Input voltage	12V/24V
Rated current for DC	3.75/1.875A
Color	Gray and black
Power	45W
Size	69x34.5x52.4 cm
Temperature range	-4°F to 68°F in ambient temperature of 77°F

Model no	EP24413
Capacity	50L
Power supply	DC 12V/24V AC 100-240V (with adaptor) 50-60Hz
Input voltage	12V/24V
Rated current for DC	4.1A/2A
Color	Gray and black
Power	50W
Size	72.3x36x45.8 cm
Temperature range	-4°F to 68°F in ambient temperature of 77°F

APP Operating



Mobile APP Control by bluetooth
IOS & Android

APP Connecting Operation: Download APP Smart Car Fridge from App store or Google Play, then open the blueooth and APP, search the equipment, choose the fridge and there will be 'AP' shown on the fridge display panel. Press setting button  to connect mobile and fridge.

Troubleshooting

Fault	Solution
Refrigerator is not working	Check if power supply is malfunctioned or not. Check if the plug and socket are connected well. Check if the fuse is burnt or not. Compressor starts delay protection for 3 mins after switching on.
Water flowing sound from the refrigerator	It is the flowing sound of the refrigerant which is normal phenomenon.
The compressor is slightly noisy when starting	The noise will be less after the compressor works stably which is normal.
F1 code display	It is protection mode of low car voltage which can be solved by setting battery protection button from H to M or from M to L.
F2 code display	It is the protection mode of overloaded fan. Please turn it off and restart it after 30 mins.
F3 code display	It is the protection mode of frequent working compressor. Please turn it off and restart it after 30 mins.
F4 code display	That means compressor is overloaded or working at a low speed. Please turn it off and restart it after 30 mins.
F5 code display	It is the protection code of overheated compressor module. Please move it to a ventilated area, turn it off and restart it after 30 mins.
F6 code display	No parameter can be detected by the controller. Please restart it.
F7 or F8 code display	It is the erroneous protection code of temperature sensor. Please check the sensor terminal.

Attention

- Make sure to connect power to the suitable voltage socket.
- The refrigerator can be switched on after being unpacked and left on the ground for more than 6 hours.
- Keep the refrigerator horizontal when it is running. The tilt angle must be less than 5° for long time running and be less than 45° for short running.
- The refrigerator must be well ventilated for heat dissipation.
- The refrigerator should be placed somewhere well-ventilated away from heat source.
- Do not turn the refrigerator upside down for drainage.
- Do not expose it to rain or soak it in water.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us!
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.

