



10-outlet Power Manager with Surge Protection and Noise Filtering

RF-HTS115



Congratulations on your purchase of this Rocketfish Power Manager with surge protection and noise filtering.

Your power manager:

- Reduces energy consumption to save environmental resources and lower your electric bill
- Provides surge protection for sensitive electronic devices
- Incorporates noise filtering to provide "clean" power that will maximize the performance of your equipment

Features



*Two AC adapter spaced outlets on the far left end and 2 outlets on the far right end

- 1 One master outlet** - controls power to the five master-controlled outlets.
- 2 Data line surge protection** - protects your incoming RJ11 (phone) or RJ45 (Ethernet) line from surges and spikes.
- 3 Power LED indicator** - Lights to indicate that the power manager is receiving adequate power from the AC outlet.
- 4 Protected LED indicator** - Lights when the surge protection feature is working properly. If this LED does not light or goes out, the surge protection feature has reached full capacity and can no longer absorb additional surges and spikes. The power manager should be replaced if this light goes out.
- 5 Grounded LED indicator** - Lights when a properly grounded AC outlet is detected. If this LED does not light, we recommend that you contact a certified, licensed electrician to inspect your wiring.
- 6 7 ft (2.1 m) Soft-Flex™ power cord with right-angle/off-set plug** - enables placement of the Power Manager in the desired location, furniture to be placed as close as possible to the wall and will not block the second AC outlet.
- 7 Main power switch/circuit breaker** - controls power to all AC outlets on the Power Manager, and allows the unit to be reset in the event of a circuit overload (after the overload condition has been resolved).
- 8 Coaxial cable surge protection** - protects your incoming coaxial cable line from surges and spikes.
- 9 Four AC adapter spaced outlets** - accommodate bulky AC adapter plugs.

- 10 Five master-controlled outlets** – automatically shut down to conserve energy when the device plugged into the master outlet is turned off.
- 11 Four always-on outlets** – provide continuous power regardless of Master/Master-controlled outlets state.
 - **3,450 joules surge protection** – Protects your equipment from damaging power surges and spikes.
 - **70 dB EMI/RFI noise filtering** – Ensures that your equipment receives only clean power for maximum performance.
 - **Audible alarm** – Sounds when the surge protection feature has reached full capacity and can no longer absorb surges and spikes. The power manager should be replaced if this alarm sounds.
 - **Power cord labels** – attach these labels to your power cords (near the plug end) to help identify which cord is attached to which device in the event that one should need to be unplugged for any reason. The labels are pre-printed for convenience, and the blank labels can be customized for unique devices.

Operating instructions

- 1** Plug the power cord of the Rocketfish Power Manager into a standard 120V AC outlet. If the LEDs do not light up, press the main power switch/circuit breaker on the side of the unit.
- 2** Plug the power cord of your primary home theater device, such as a TV, into the *Master* outlet of the Power Manager. When this device is powered off or goes into a SLEEP or STANDBY mode, power to the devices plugged into the *Master-controlled* outlets will automatically be shut off, saving energy by preventing them from drawing any standby current.
- 3** Plug the power cords of your secondary devices, such as a Blu-ray/DVD player, A/V receiver, CD player, etc., into the *Master-controlled* outlets of the Power Manager.

Note: Do not plug any device into a *Master-controlled* outlet that you wish to use while the power of the primary device plugged into the *Master* outlet is powered off, as these outlets only provide power to the connected devices while the primary device is powered on.
- 4** Plug the power cords of any devices that require constant power, such as a DVR/PVR, or devices that you wish to use while the primary device is powered off, into the *Always-on* outlets of the Power Manager.
- 5** Connect the incoming coaxial cable source (i.e., the cable jack on the wall or incoming satellite line) to the coaxial jack marked IN on the Power Manager.
- 6** Connect a separate coaxial cable from the coaxial jack marked OUT on the Power Manager to the coaxial input jack of the cable/satellite set-top box.
- 7** Connect the incoming phone (RJ11) or Ethernet (RJ45) line to the data line jack marked IN on the Power Manager.
- 8** Connect a separate phone or Ethernet cable from the data line jack marked OUT on the Power Manager to the corresponding input jack (phone or Ethernet) on the device (i.e., satellite set-top box).

Note: the data line jacks are combo (RJ11/RJ45) jacks, meaning they will accept either a RJ11 or RJ45 plug. They will not accept both types of plugs simultaneously.

- 9** After all devices have been properly plugged into the Power Manager and powered on, when you power the primary device that is plugged into the *Master* outlet on and off, the secondary

devices that are plugged into the *Master-controlled* outlets will automatically power on and off. Devices that are plugged into the *Always-on* outlets will not be controlled by the primary device, and must be powered on and off separately as desired.

Note: Should the *Master-controlled* outlets not power on and off as described when the primary device plugged into the *Master* outlet is powered on and off, it is possible that the primary device draws too much current while in the OFF or STANDBY mode. In the event this should occur with your equipment, try plugging a different primary device into the *Master* outlet.

Specifications

- Load rating: 15 amps
- Line voltage: 125V AC @ 60 Hz
- Surge protection: 3 lines (L-N / L-G / N-G)
- Maximum surge current: 180,000 amps
- Maximum energy dissipation: 3,450 joules
- Clamping voltage: L-N / L-G / N-G = 400 volts
- EMI/RFI noise filtering: Up to 70 dB
- Standby power consumption: 0.99 watts
- UL-1449 certified

Safety precautions

- RISK OF ELECTRIC SHOCK–Use only in dry locations and only indoors.
- DO NOT plug into another relocatable power tap.
- DO NOT “daisy chain” surge protectors.
- DO NOT use with any aquarium equipment.
- DO NOT use if correctly grounded outlets are not available.
- DO NOT install this device if there is not at least 30 feet (10 meters) or more of wire between the electrical outlet and electrical service panel.

One-year limited product warranty

See included warranty sheet, visit www.rocketfishproducts.com or call 800-620-2790 for additional connected equipment and product warranty information or for customer service.



© 2012 BBY Solutions, Inc., All Rights Reserved.
 Distributed by Best Buy Purchasing, LLC
 7601 Penn Avenue South, Richfield, MN USA 55423-3645
 ROCKETFISH is a trademark of BBY Solutions, Inc. All other products and brand names are trademarks of their respective owners.