


IMPORTANT NOTE:

Some Samsung MHL-enabled devices require the included adapter to be connected to the USB/MHL connector on the Samsung device. The micro USB connector on the MHL cable then connects to the adapter. Devices that require the adapter include the Galaxy S[®] III, 4, and 5, and Galaxy Note[®] II, 3, 4, and Edge, and other Samsung products.

Before using your new product, please read these instructions to prevent any damage.



NOTA IMPORTANTE:

Algunos dispositivos compatibles con MHL de Samsung requieren que el adaptador incluido se conecte al puerto de USB/MHL en el dispositivo Samsung. El conector micro USB en el cable MHL se conecta después al adaptador. El dispositivo que requiere el adaptador incluye los Galaxy S® III, 4 y 5, y Galaxy Note® II, 3, 4 y Edge así como otros productos de Samsung.

Antes de usar su producto nuevo, lea este instructivo para prevenir cualquier daño.

