


# ROKU<sup>®</sup>


Select Series




## What's included



Roku Select Series TV



TV power cord  
included for 50" - 85"  
models only



x 4 screws

Stand screws



TV stands




Roku TV Remote

## What you need



Phillips head  
screwdriver




Laptop or mobile  
phone for activation



Internet connection

## STEP 1: Set up your TV



### **A** Prepare a surface

Put a soft covering like a blanket down onto a clean, flat surface (make sure it's larger than the TV) and place the TV on it.

### **B** Attach the stands


Use a screwdriver and included screws to attach the stands.

### **C** Set TV upright


Place your TV on a stable, flat surface.

## Mounting your TV?

For instructions, skip these steps and visit [go.roku.com/tvmount](https://go.roku.com/tvmount)




## STEP 2: Plug TV in and power your remote



### A Connect your TV


Plug your TV into a power outlet. It should turn on automatically. If it doesn't, press the power button.



### B Power your remote

See the remote features card on how to use your Roku TV remote.

## STEP 3: Activate your TV



### Connect your TV

Follow the instructions on your TV screen. Activate your TV by using your computer or smartphone to link a Roku account.



### IMPORTANT

Roku never charges for activation support.

## Frequently asked questions

---

### Why do I need an internet connection?

You'll need an internet connection to set up your TV, stream your favorite channels and for automatic software updates.

### Why should I enter a payment method?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

## Get to know your TV

---



**HDMI** - Game consoles, DVD players



**Composite (available on some models)** - Analog devices, older game consoles



**Antenna/Cable** - Digital antenna, cable connection

## Audio connections



**HDMI ARC or eARC (recommended)** - AV receivers, soundbars



**Optical (S/PDIF)** - AV receivers, soundbars



**Headphone Jack (available on some models)** - Wired headphones

## Other connections




**USB** - Flash drive for media playback



**Ethernet (available on some models)** - Wired internet connection

# ROKU Remote features



## Power your remote

Includes pre-installed batteries. Pull out the tab on the back of your remote. It will pair to your TV automatically.



## Voice search & control

Quickly search across thousands of apps, play entertainment, control your streaming, and more with your voice.



## Find your lost remote

Use the Roku mobile app or press the TV's power button to bring up the options menu.



## Live TV in a click

Start watching free live TV and local news with just one press.



## Save your faves

Personalize shortcuts to open any app, turn on closed captions, and more with the quick launch button.

# ROKU

© 2026 Roku, Inc. All Rights Reserved. Roku, the Roku logo, and the purple d-pad and purple fabric tag designs are trademarks or registered trademarks of Roku, Inc.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Confidential unpublished works. Copyright 1992-2019 Dolby Laboratories. All rights reserved.

## Need help?

For setup help or support, visit or call

[go.roku.com/TV](https://go.roku.com/TV)

**1-816-272-8106**

4:00 am - 10:00 pm PT

