

INSIGNIA

QUICK SETUP GUIDE

86" Compact Folding Light Stand

NS-DLS86BK


PACKAGE CONTENTS

- Light stand
- Carrying case
- *Quick Setup Guide*

FEATURES

- Legs fold in a reversible way to minimize folded height
- Versatile and compact for easy set up
- Five-section light support with screw knob section locks
- Perfect for studio lights, flash heads, umbrellas, reflectors, and background supports
- Offers sturdy support in the studio and is easy to transport to other locations
- Compatible with cameras that have a tripod mount

Flat size (W×H): 9 × 12 in. (228.6 × 304.8 mm)
Final folded size: 9 × 6 in. (114.3 × 304.8 mm)



#	ITEM	DESCRIPTION
1	1/4" mounting screw	Use this screw to mount a device, such as a studio light, flash head, or umbrella bracket. Note: Some studio flash heads or umbrella brackets slide all the way over this mount area and fasten in place with a locking clamp.
2	Section knob	<ul style="list-style-type: none"> • Tighten to lock each section in place. • Loosen to extend or shorten each section.
3	Leg position knob	<ul style="list-style-type: none"> • Tighten to lock the leg positions. • Loosen to position the legs.
4	Leg extension knob	<ul style="list-style-type: none"> • Tighten to lock the leg extensions. • Loosen to extend or shorten the leg extensions.

Before using your new product, please read these instructions to prevent any damage.




USING YOUR LIGHT STAND


1 Loosen the leg position knob.




2 Pull outward on the legs and set upright.



3 Move the legs to the position you want, then tighten the leg position knob.




4 Loosen each leg extension knob, then extend the legs to the length that you want and tighten the knobs.



5 Attach your studio light, flash head, umbrella, or other device to the mounting screw.

6 Loosen each section knob, then extend each section to the length you want and tighten the knobs.



IMPORTANT SAFETY INSTRUCTIONS

- To prevent damage to your lighting equipment or injury to you or others, read the following safety precautions before using the stand.
- Read and understand all instructions before using.
- Keep these instructions.
- Close supervision is necessary when any appliance is used by or near children. Do not leave the appliance unattended while in use.
- Do not place the light stand on an uneven surface. Your stand may tip over and cause property damage or personal injury.

NOTE: Do not exceed the 5.5 lb (2.5 kg) maximum load capacity of this light stand. Avoid mounting heavier or unbalanced loads on the stand to prevent an accidental fall, bodily injury, or damage to your equipment.

SPECIFICATIONS

Maximum operating height	86.6 in. (220 cm)
Minimum operating height	18.9 in. (48 cm)
Folded height	19.3 in. (49 cm)
Net weight	2.9 lbs (1.3 kg)
Load capacity	5.5 lbs (2.5 kg)
Main material	Aluminum

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2018 Best Buy. All rights reserved.
Made in China

