

INSIGNIA™

DEVICE CODES CÓDIGOS DE LOS DISPOSITIVOS

Three-device Universal Remote

Control remoto universal
para tres dispositivos

NS-RMT3D21



Device codes/Códigos de los dispositivos

TV Device Codes/Códigos de dispositivos de televisión

Affinity	3717, 3870, 3577, 3716
Aiwa	3332, 1362
Akai	1675, 3332
AOC	3720, 2691, 1365, 2014, 2087
Apex Digital	2397, 4347, 4350
Ario	2397
Asus	3340
Atak	2397
Atvio	3638, 4398, 3636, 3879
Atyme	2746
Audiovox	1564, 1276, 1769, 2121
Auria	4748, 2087, 2014, 2277, 2855
Avera	2397, 2049
Avol	2735, 4367, 3382, 3118, 1709
Axess	3593
Blu:sens	2735
Bolva	2397
Broksonic	1892, 3118
Calypso	4748
Champion	1362
Changhong	4629
Citizen	1892
Coby	3627
Contex	4053, 4280
Craig	3423, 1687
Crosley	3115
Curtis	2855, 3577, 2466, 3895, 2352, 2397, 3939, 4035, 3636, 3382, 3717, 4139
Curtis Mathes	1661
Daewoo	1661, 3115, 3879
Dell	1749
Digitrex	4207
Disney	1892
Durabrand	1595, 3879
Dynex	2049, 1463, 1780, 2184

Electrograph	1755
Electrohome	1670
Electron	2466, 2855
Element	3559, 1687, 4398, 2183, 2964, 5173, 4635, 4910, 1886, 4217, 4740
Element-Roku	4398, 4740
Elite	1457
Emerson	1864, 1963, 1394, 1886, 1595, 3623, 1661, 2183, 3559
Envision	1365, 2087, 2014
EQD Auria	2014, 2087, 2277
ESA	1963, 1595
eTec	2397
Exorvision	3953
Favi	3382
Fisher	1362
Fluid	2964, 3559
Furrion	3332, 4093, 5410
Gateway	1755
GE	1447
GFM	1864, 1886, 1963
GHIA	5144, 5196
GPX	3980, 3977
Haier	2309, 1749, 1748, 3382, 1753, 3429, 2293, 4398, 2214
Haier-Roku	4398
Hannspree	1348, 2786
Harper	3332
Hewlett Packard	1860
Hisense	3519, 4740, 4618, 2183, 5185, 1660, 3382
Hisense-Roku	4740
Hitachi	1643, 4398, 5102, 4455, 2214, 3382, 3332, 0679, 5446
Hitachi-Roku	4398
Hiteker	3118
HKPro	3879, 2434, 5228
HP	1860
iLo	1463, 1394
InFocus-Roku	4398
Insignia	2049, 1780, 4487, 3227, 5213, 1564, 1641, 2184, 1892, 1423, 1660, 1963
Insignia-Roku	4487
iSymphony	3382, 3429, 3118, 3094

JVC	1774, 1601, 3393, 2321, 2271, 4107, 4398, 5182, 4105, 4053, 1670, 4367, 1892, 3879, 4280, 5228
JVC-Roku	4398
KC	4182
KDS	1687
Kenmore	3953
LeEco	4007
Legend	2397, 2352, 1749, 2309
Lexus	3638
LG	1840, 1860, 2731, 1423, 4397, 2358, 1749, 4398, 1753
MAG	1687
Magnavox	3623, 1866, 2372, 1963, 1454, 1365, 1755, 4398, 1867, 4740, 1394
Magnavox-Roku	4398, 4740
Marantz	1454
Maxent	1755
Memorex	4686, 1892, 1670, 1687, 2049
Mitsubishi	1250, 1797
Mitsui	1123, 3638, 3673
Naxa	4093, 2104, 2735, 3382, 3423
NEC	3257, 1797, 3000, 2293
NetTV	1755
Nexus	1564, 3519, 2183
Norcent	1365, 2087
NuVision	1657, 4347
oCOSMO	3899, 4139
Ölevia	1610
Onn	4398, 5348, 1709, 3024, 3078, 5118
Onn-Roku	4398
Optimus	0679
Orion	1463, 1670, 3540, 1892
Panasonic	1480, 1291
Philco	1963, 1394, 5377
Philips	2800, 1867, 2372, 3069, 1454, 3623, 3396, 1866, 1744, 4398, 1963, 1755, 1365, 1394
Philips Magnavox	3396, 1866, 3623
Philips-Roku	4398
Pioneer	0679, 1260, 1457, 2434
Planar	0679

Polaroid	1523, 4035, 1769, 1276, 1687, 1767, 3942, 2121, 3382, 2434, 3118
Portland	1661
Prima	1753, 2049, 1749
Proscan	1447, 3577, 3382, 2183, 3717, 3332, 4494, 3636, 3895, 3953, 4495, 4035, 4053, 4491, 3939, 4483, 4375, 4500, 2746, 3429, 3559, 4093
Proview	1687
Pyle	2196
QFX	3593
QuantumFX	3593
Quasar	1291, 4207, 3899, 4367, 3382, 5221
RCA	2746, 2434, 2247, 4214, 3577, 1781, 4398, 3382, 4740, 3332, 3717, 2932, 3895, 2187, 4629, 4488, 4494, 3953, 2183, 4623, 3636, 3939, 2855, 4053, 3519, 4491, 4495, 4627, 0679, 4035, 4483, 4625, 5223, 1661, 5377, 3938, 4093, 1670, 5173, 1447
RCA-Roku	4398, 4740
Roku	4398, 4740
Sampo	1755
Samsung	2051, 1632, 5386, 5371
Sansui	1892, 3540, 1670, 1463, 4053, 3564, 4280, 3559
Sanyo	1142, 1362, 4168, 4740, 2049, 4667, 3488, 1480, 1564
Sanyo-Roku	4740
Sceptre	3899, 4139, 2528, 5393
Seiki	3953, 4635, 2964, 3560, 3559, 4217, 3382, 4794
Seura	4751
Sharp	2360, 1659, 3519, 3394, 4740, 4618, 3720, 4507, 2214, 4398
Sharp-Roku	4740, 4398
Sigmac	3477, 3423
Silo Digital	3899, 4494, 3477, 4182
SkyVue	4135, 2360
Skyworth	5340, 4542
Sony	0810, 4448, 4189
Spectroniq	1687
Speler	4105, 4041, 2434
SunBriteTV	2528, 4139, 1610
Superscan	1963
Supersonic	3593, 2104, 1753
SVA	1963
Sylvania	1963, 1864, 1886, 1394, 1595, 3332, 3577, 4053
Symphonic	1963, 1595, 1394

TCL	4398, 2434, 3183, 5446, 3879
TCL-Roku	4398
Technicolor	3577
Toshiba	2724, 3945, 5213, 4885, 5394
Upstar	4182, 4405, 3899
V7 Videoseven	2087
Vidao	2397
Videoseven	2087
Viewsonic	2014, 2277, 2087, 3706, 1755, 2049, 1860, 1564, 1365
Viore	3382, 2352, 3118, 2104, 3429, 3094
VisionQuest	1687
VIZIO	1758, 3758, 4905, 5454, 4723, 2707, 2757, 3415, 2512
W Box Technologies	4686
Westinghouse	1712, 4797, 3559, 3382, 4398, 5173, 4910, 2293, 3094, 4139, 3560, 4635, 2397, 3908
Westinghouse-Roku	4398
White Westinghouse	1661
Wyse	1365
Xococo	1753, 2049, 1749
Zenith	1423, 2731, 1661, 1365, 2358, 1463

STB Device Codes/Códigos de dispositivos STB

Access Communications	1376, 2187, 4537
ADB	2586, 1481, 1998, 2254, 3028
Altice USA	3885, 1376, 6351, 1877, 3560, 1982
Amino	1615, 1481, 1898, 3605, 2482, 4437, 1998, 3028, 3426
Armstrong	1376, 3560
Arris	1376, 2378, 1982, 1998, 2187, 0869, 5912, 1877, 5889, 5097, 6400, 0858, 5537, 5942
AT&T	1377, 6268, 0858
AT&T U-verse	0858
Atlantic Broadband	1376, 1877, 1982, 3560, 4079
Axtel	4458
Bell	0775, 1998, 5537, 1877, 5097
Bell Aliant	1998
Bell Fibe TV	1998, 5097, 5537

Bell MTS	1998, 5097, 5537
Bell Satellite TV	0775
Blue Ridge Communications	1877, 3560
Buckeye Broadband	1376, 1877, 2187, 4079
Cable Axion	1376
Cable One	1376, 3560, 1877
Cablecom Mexico	1376
Cablemás	1376, 1877
Cablevisión Mexico	1376, 4375, 4537
CenturyLink	1998, 0858
Channel Master	3118
Cincinnati Bell	1877, 1376
Cisco	1877, 1982, 2947, 0858, 3028, 2345, 2378, 5912, 1998, 4315, 3294, 4374, 5484, 2826, 4450, 4514, 5942
Cogeco	1376, 1982, 3560, 4537
Comcast	1982, 1376, 1877, 3560, 2187, 4079, 4443, 4537
Cox Communications	1877, 1376, 1982, 4315, 3774, 3560, 6400
DIRECTV	1377, 6268, 3724
DISH	0775
Dish Mexico	0775, 6068
DISH Network	0775
EastLink	1376, 2187
Echostar	0775
Entone	3426, 1615, 1898, 4437
Evolution Digital	2479, 4079, 2746, 4315, 3560
Frontier Communications	2378, 1998, 3560, 0775
Google Fiber	3666
Ignite TV	1982
Izzi Telecom	1376, 6195, 4375, 4537
Kaon Media	4458, 2746
Liberty Cablevision	1376
Maxcom	1998
Mediacom	1376, 3560, 1982, 1877
Megacable	1376, 6286, 4374, 4450, 4514, 4375, 4537, 4883
Midco	1376, 1982, 3560, 2826, 4079
Motorola	1376, 0869, 2378, 1998, 0858, 1982, 4375, 5097, 3469

Moxi	2187
Optimum	3885, 1376, 6351
Pace	1982, 1376, 1377, 1877, 3469, 3560, 1998, 0858, 6195, 4537, 5370
Philips	1377, 2378, 3560, 2619, 3469
Pioneer	1877
RCN	1376, 3560, 1877
Rogers	1877, 1376, 5484, 1982, 2826, 3294, 4537
Sagemcom	3885, 5842
Samsung	1377, 1877, 1982, 2947, 3928, 6268
SaskTel	1998
Scientific Atlanta	1877, 0858, 1982, 2345, 3028, 2378, 2826
Service Electric	1376, 1982, 1877, 2187
Shaw	1376, 1877, 1982, 2187, 4537
Shaw Direct	0869, 0775
Sky Mexico	3469, 2619, 1377
Sparklight	1376, 3560, 1877
Spectrum	1877, 1376, 2187, 3560, 3294, 4537
Suddenlink	1877, 1376, 3560, 6351, 3885, 1982
Tbaytel	1998
TDS Telecom	0775, 1376, 3028, 1877, 1982
Technicolor	1377, 1877, 1982, 5484, 5912, 2947, 6286, 6068, 6195, 3469
TeleCable	1376
TELUS	5912, 3028, 0775, 5942
Time Warner Cable	1877, 1376, 3294, 2187, 3560, 4537
TiVo	3560, 3724, 1377
Totalplay	4589
TVision Home	5370, 1998
U-verse	0858
Verizon	2378, 5889, 6326
Vidéotron	1877, 2947, 1376, 1982
Vmedia	4596
Wave Broadband	1376, 1877, 4079, 2479, 3560, 2187
WOW!	1877, 1376, 2187, 2479, 3560, 2826, 3294
Xfinity	1982, 1376, 1877, 3560, 2187, 4079, 4443, 4537
Xtream	1376, 3560, 1982, 1877
ZTE	6286

AUDIO Device Codes/Códigos de dispositivos de AUDIO

iLive	3175
Inkel	3770, 4090, 3793
Insignia	3951, 2169, 2472, 2966, 3770, 4424, 1077
Integra	1805, 3860, 2730, 4023, 4014, 2503, 3992
Jamo	4941
JBL	3756, 2241, 3391, 3535, 5132, 0110
JVC	1676, 2040, 3049, 2331
Kenwood	1570, 1293
Klipsch	4941, 4198, 4200, 5152
LG	3217, 2676, 3509, 2197, 4043, 3996, 1293
Magnavox	1831, 1269, 3282
Majority	5506
Marantz	1289, 2114, 3772, 1269, 3347
McIntosh	1289
Megacra	5271
Monoprice	4505
Monster Cable	4987
Onkyo	1805, 2730, 3860, 4023, 2503, 4041, 4014, 3992, 3984, 5094
Onn	5041, 5412, 5042, 5414, 5415, 5043
Optimus	1023
Panasonic	3323, 2967, 3309, 3055, 2452, 3767, 1676
Paradigm	4536, 4846
Peerless-AV	5153
Philco	1831
Philips	1831, 1269, 4105, 2459, 3776, 3379, 3282, 3801, 2311, 3652, 2675, 4012
Pinnacle Speakers	3774, 3728
Pioneer	1935, 3057, 2432, 1023, 3956
Polk Audio	4431, 1289
Proficient	3661
Pyle	4333
RCA	2041, 2611, 3297, 2719, 2655, 3969, 1023, 2544, 5490
RichSound Research	5138
Roku	5495
RSR	5138

Samsung	2660, 1868, 2809, 3320, 3382, 3154, 2137, 1304
Samsung Harman/ Kardon	3320
Sanyo	4176, 3282
Sceptre	5351
Sennheiser	5330
Sharp	3097, 3736, 3929
Sherbourn	3763
Sherwood	1077, 1567, 3120, 3136, 2169, 3793, 4090, 3770
Sherwood Newcastle	1567, 2169
SnapAV	5107
Sonos	3919
Sony	1622, 3700, 2172, 4315, 1759, 1822, 2522, 2475, 1758, 3257, 2582, 3487, 4457, 0158, 4285, 4366, 2610
Soundcore	5578
SpeakerCraft	3661
Stereophonics	1023
TaoTronics	4672
TCL	4672, 5385
Toshiba	3627
VIZIO	3935, 2454, 5095, 4911
Yamaha	2467, 2116, 3580, 3030, 2458, 3325, 3917, 4269, 2021, 0176
Zenith	1293, 2197
ZVOX	2332, 3913, 2334

INSIGNIA™

www.insigniaproducts.com
1-877-467-4289 (U.S. and Canada/EE.UU. y Canadá)

INSIGNIA is a trademark of Best Buy and its affiliated companies.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2022 Best Buy. All rights reserved.

INSIGNIA es una marca comercial de Best Buy y sus compañías asociadas.
Distribuida por Best Buy Purchasing, LLC
7601 Penn Avenue South, Richfield, MN 55423 E.U.A.
© 2022 Best Buy. Todos los derechos reservados.

V2 ENGLISH/
ESPAÑOL
22-0134