

SAVE THESE INSTRUCTIONS

For Customer Care, product operation information or problem resolution, call toll-free **1-877-654-1991**.

IMPORTANT SAFETY INSTRUCTION

- Do not look directly at the light and do not shine into eyes of others. Eye damage may occur.
- Keep lamp away from materials that may burn.
- This product is not a toy and not intended for small children. Adult supervision is necessary.
- LED Module is not replaceable. Do not break or pull out LED bulbs.

TO USE:

1. Install batteries inside the battery compartment.

See BATTERY INSTALLATION.

If using power cable, ensure the cable meets requirements:

AC/DC Adapter (UL approved) :

Input : AC 100 - 240V, 50 - 60 HZ

Output : 4V DC, 400mA with a male plug

USB Cable : USB DC 5V to DC 4V step-down module converter cable with a male plug.

2. To position the LED light source, simply bend the stem or flex-neck as needed to point the light. Hold the body while adjusting the flex-neck. DO NOT FORCE the flexible stem into any extreme positions as damage may occur.

3. Turn the LED light On and Off by using the power button located on the front-upper side of the LED light source. The LED light source will last 100,000 hours.

4. Model UBL012:

LED light source has one light intensity. Slide power button for ON/OFF operation.

5. Model UBL014, UBL018, UNL013N3:

LED light source has a 2-step light intensity: HIGH, LOW.

Press power button once for HIGH, once again for LOW, and once more for OFF.

BATTERY INSTALLATION:

1. To install batteries, slide battery compartment door away from the stem while slightly depressing the door near the tab. Alkaline batteries are recommended.

2. Install 3 AAA batteries inside the battery compartment. Negative terminals of the batteries should point toward the spring.

3. Replace battery compartment door by laying it on open compartment and sliding door toward the stem to engage the tabs to the compartment, a click should be heard as it locks into place.

Notice: Only replace batteries as a simultaneous set and do not mix with older batteries. Replace batteries as needed. Do not install backwards, attempt to recharge non-rechargeable batteries, put in fire, or mix with other battery types - may explode or leak causing injury.

BATTERY WARNING: Keep away from children. If any amount of battery leakage comes into contact with skin, eyes or mouth, immediately flush area with cool running water (do not use hot water). If swallowed, promptly see a doctor, or call the 24-hour National Button Battery Ingestion Hotline - 1-202-625-3333. They will accept collect calls from U.S. and Canadian citizens. If injury appears serious, call 911.

NOTE: The important safety instructions appearing in this instruction sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care must be used with any electrical product.

CAUTION: Any changes or modifications to product not expressly recognized by INTEK America, Inc. voids INTEK's responsibility for proper function of product.

One-Year Limited Product Warranty

The manufacturer warrants the unit for a limited time to be free from defects in material and workmanship. If any part is found to be defective during the warranty period, your sole and exclusive remedy will be repair or replacement, at the manufacturer's option and expense, of the defective part except for the shipping cost. It is the responsibility of the consumer to pay the shipping costs to return the unit to the manufacturer.

This warranty is valid for the original consumer only with original proof of purchase and is not transferable. This warranty does not apply in cases of abuse, mishandling or unauthorized repair. ANY IMPLIED WARRANTY, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS HEREBY LIMITED IN DURATION TO THE APPROPRIATE WARRANTY PERIOD SET FORTH ABOVE. In no event shall the manufacturer be liable for any consequential or incidental damages attributable to this product. This warranty gives you specific legal rights. You may have other legal rights that vary according to the laws of the State in which you reside.

For more details, or to obtain service under this warranty, please contact us at 877-654-1991. Please retain original proof of purchase to ensure that your product is recorded and warranty information received.

Return Instructions

1. Before you return your unit, call 877-654-1991 for a Return Authorization Number (RA#), shipping instructions, and the manufacturer's address.
2. Make a photocopy of the proof of purchase (receipt), showing original purchase date, and include it inside the package (DO NOT send the original receipt).
3. Pack the unit in its original carton, or equivalent, and write the RA# clearly on the outside of the box.
4. Ship the unit to the address provided. Save your shipping receipt.

IMPORTANT!

You must call us to obtain an RA# before returning a defective product. No shipments will be accepted without a valid RA#.



Toll-Free 877.654.1991 | www.ultrabriteidea.com

An INTEK Brand | We Care. We Share. ©2017 INTEK America Inc.
18528 S. Dominguez Hills Drive, Rancho Dominguez, CA 90220