Bar 5.1

5.1-Channel 4K Ultra HD Soundbar with True Wireless Surround Speakers

Quick Start Guide

Note: *For complete information about using all of your JBL Bar 5.1, download the full Owner's Manual from www.jbl.com.*

1 What's in the box





* Power cable numbers varied by regions

2 Place your soundbar

2a. Place the soundbar on the table

2b. Wall mount the soundbar

Use tape to stick the wall-mounted paper guide on the wall, push a pen tip through the center to mark the wall-mounted bracket location and remove the paper

Screw the wall mount brackets on the pen mark, fix the screw at the back of soundbar, then hook the soundbar on the wall.

2c. Dock the wireless speakers

Wireless speakers charge during soundbar standby mode.

3 Connect your soundbar

3a. Connect to your TV



3b. Connect to other devices

4 Power your system



5 Control your soundbar

5a. Top Panel

5b. Remote control

*Switch between HDMI ARC / HDMI 1 / HDMI 2 / Optical/ AUX/ Bluetooth/ USB
**Switch between movie / music / game / sports sound mode or press and hold 5 seconds to reset default audio setting

5c. Wireless Speakers



6 Bluetooth® connection

6a. Press Remote Control Bluetooth button to enter Bluetooth source

6b.

Remark: Press and hold Remote control Bluetooth button for 3 seconds if you want to pair another mobile device.

7 Set up Wireless Surround Sound

Audio Calibration will optimize the wireless speaker sound settings for a better surround sound experience.

7a.

7d.

7b.

7c.

8 JBL SoundShift®

Press Soundshift button to enable Soundshift feature.

While SoundShift is on, play and pause your music source to enjoy auto-switch between your mobile devices (A) and TV (B). When Soundshift is off, press the Bluetooth button on the Remote Control to listen to Bluetooth source.

9 Respond to Your TV Remote Control

Use your own TV remote control to control your soundbar

9a. For most Samsung, LG, Sony and Vizio TVs

The soundbar responds to your TV remote control automatically. Press and hold soundbar remote control SHUFFLE button if you want to disable the function.

9b. For other TVs

Please manually program the soundbar to respond to your TV remote control step by step. First, press and hold VOLUME+ and SOURCE button to enter learning mode.

Then, press POWER button on the soundbar and press POWER button on the TV remote control.



Follow the same procedure for VOLUME - and VOLUME +. For mute, press both VOLUME + and VOLUME - button on soundbar and press MUTE button on TV remote control. Press and hold VOLUME+ and SOURCE button on soundbar again and now your soundbar responds to your TV remote control.

10 Product Specifications

Total Maximum Power	510W
Soundbar Maximum Power	330W
Subwoofer Maximum Power	130W
Surround Speaker Maximum Power	2 x 30W
Surround Speaker Play Time	10 hours
Battery charge time	< 3 hours
Soundbar Transducer Size	4 x 2.25" racetrack drivers 3 x 1.25" tweeter
Subwoofer Transducer Size	10"
Max SPL	104db
Frequency Response	35Hz to 20kHz
Operating Temperature	0°C~ 45°C
Audio Inputs	1 Analog, 1 Optical, Bluetooth, USB
HDMI Video Inputs	1
HDMI Video Outputs (HDMI ARC/eARC supported)	1
HDMI eARC Version	2.2
Bluetooth Version	4.2
Bluetooth Profile	A2DP V1.2/ AVRCP V1.5
Bluetooth Frequency Range	2402MHz-2480MHz
Bluetooth Max Transmitting power	9dBm (EIRP)
Bluetooth Transmitter modulation	GFSK, π/4 DQPSK, 8DPSK
Bluetooth Transmitting frequency	79 non-overlapping
5.8G Max Transmitting power	9dBm (EIRP)
Soundbar Dimensions (W x H x D)	1149 x 58 x 93 (mm) / 45" x 2.3" x 3.7"
Soundbar Weight	3.5kg / 8.6 lbs
Subwoofer Dimensions (W x H x D)	400 x 305 x 305 (mm) / 16" x 12" x 12"
Subwoofer Weight	10kg / 26.7 lbs
Surround Speaker Dimensions (W x H x D)	150 x 35 x 60 (mm) / 6.0" x 2.0" x 3.7"
Surround Speaker Weight	0.3kg / 1.3 lbs
Packaging Dimensions (W x H x D)	1335 x 370 x 453 (mm) / 52.7" x 14.9" x 17.9"
Packaging Weight (Gross)	20.6kg / 45.1 lbs

CAUTION:
This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

There are no restrictions in use in EU.

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência em sistemas operando em caráter primário.
Este produto está homologado pela ANATEL, de acordo com os procedimentos regulamentados pela Resolução 242/2000, e atende aos requisitos técnicos aplicados.
Para maiores informações, consulte o site da ANATEL - www.anatel.gov.br

ANATEL

Top/case sapoc. JBL
Нижняя/нет Чехла Активная
Subwoofer Front Firing
Фронтальный Корпус Излучатель Вверх/Сзади
Harman Consumer Group International, Inc.
г.Стамфорд, Атлантик Стрит 400, офис 3300
Made in China/Сделано в Китае
Импортер в России ООО "Харман Интернешнл (Индастриз), Е.Л.К.".
Адрес импортера: 115162
Уведомление о продаже: импортер www.harman.com/ru тел. +7-800-700-0467
Срок службы: 5 лет
Дата производства:
Для ознакомления с информацией о производителе по пути утилизации, переработке и вторичному использованию упаковочных материалов, содержащих после разделения/сортировки знаки 1 – 7, 20 – 22, 39 – 41, 50 – 52, 60 – 62, 70 – 79, 80 – 98, обратитесь к сайту производителя.
(с. 2015 Ф. 2015 С. – 2012 ч.р.).

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. DOLBY AUDIO™ - Manufactured under license from Dolby Laboratories. Manufactured under license from Dolby Laboratories. Dolby,Dolby Audio,Pro Logic and the double-D symbol are trademarks of Dolby Laboratories.
DTS, the DTS logo, DTS:X, and the DTS:X logo are registered trademarks and the HDMI logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.
For DTS patents, see http://patents.dts.com. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Digital Surround is a trademark of DTS, Inc.
© DTS, Inc. All Rights Reserved.

FI — Guida di avvio rapido

1 Contenuto della confezione

2 Posizionamento della soundbar

3 Collegamento della soundbar

4 Accensione del sistema

5 Controllo della soundbar

6 Connessione Bluetooth

7 Impostazione suono surround senza fili

8 JBL SoundShift®

9 Controllo tramite il telecomando del TV

10 Specifiche del prodotto

NL — Snelstartgids

1 Verpakkingsinhoud

2 Plaatsing van je soundbar

3 Je soundbar aansluiten

4 Schakel je systeem in

5 De soundbar instellen

6 Bluetooth-verbinding

7 Stel draadloze Surround-Geluid in

8 JBL SoundShift®

9 Regelen met je eigen afstandsbediening

10 Productspecificaties

NO — Hurtigstartveiledning

1 Innhold i esken

2 Plassere lydplanken

3 Koble til lydplanken

4 Slå på systemet ditt

5 Betjene lydplanken din

6 Bluetooth-tilkobling

7 Konfigurer trådløs surroundlyd

8 JBL SoundShift®

9 Betjening med fjernkontrollen til TV-en

10 Produktspesifikasjoner

FR — Pikaopas

1 Mitä pakkaus sisältää

2 Aseta Soundbar

3 Yhdistä Soundbar

4 Virtaa järjestelmään

5 Ohjaa Soundbaria

6 Bluetooth-yhteys

7 Aseta Langaton Surround-ääni

8 JBL SoundShift®

9 Voidaan TV:tä kaukosäätimellä

10 Tuotetiedot

RU — Краткое руководство

1 Комплект поставки

2 Установка саундбара

3 Подключение саундбара

4 Включение системы

5 Управление саундбаром

6 Подключение Bluetooth

7 Настройка беспроводного объемного звучания

8 JBL SoundShift®

9 Управление с помощью пульта ДУ телевизора

10 Технические характеристики

SV — Snabbstartguide

1 Vad finns i lådan?

2 Placera soundbarhögtalaren

3 Anslut soundbarhögtalaren

4 Slå på systemet

5 Använda soundbarhögtalaren

6 Bluetooth-anslutning

7 Installera trådlöst surroundljud

8 JBL SoundShift®

9 Styra på fjärrkontrollen för TV

10 Produktspecifikationer

DA — Hurtigstartguide

1 Hvad er der i æsken

2 Placering af soundbaren

3 Sådan forbinder du soundbaren

4 Tænder for systemet

5 Sådan styrer du soundbaren

6 Bluetooth-forbindelse

7 Opsætning af trådløs surroundlyd

8 JBL SoundShift®

9 Betjening med fjernbetjeningen til fjernsynet

10 Produktspecifikationer

JP — クイックスタートガイド

1 同梱品

2 サウンドバーの設置

3 サウンドバーの接続

4 システムの電源をつける

5 サウンドバーのコントロール

6 Bluetooth接続

7 無線サラウンドを設定

8 JBL SoundShift®

9 お使いのテレビのリモコンに対応

10 製品の仕様

KO — 빠른시작 가이드

1 구성품

2 사운드바 배치

3 사운드바 연결

4 시스템 켜기

5 사운드바 제어

6 블루투스 연결

7 무선 서라운드 사운드 설정

8 JBL SoundShift®

9 TV 리모컨 응답

10 제품 사양

CHS — 快速入门指南

1 产品包装

2 安置您的音响

3 连接您的音响

4 开启系统

5 控制您的音响

6 蓝牙连接

7 设置无线环绕声

8 JBL SoundShift®

9 使用电视遥控器

10 产品规格

CHT — 快速入門指南

1 包裝產品內容

2 放置您的聲霸

3 連接您的聲霸

4 開啟系統

5 控制您的聲霸

6 藍牙連線

7 設定無線環繞音效

8 JBL SoundShift®

9 使用電視遙控器

10 產品規格

ID — Panduan Memulai Cepat

1 Isi kotak

2 Letakkan soundbar Anda

3 Hubungkan soundbar Anda

4 Nyalakan sistem Anda

5 Kontrol soundbar Anda

6 Koneksi Bluetooth

7 Atur Suara Kolling Nirkabel

8 JBL SoundShift®

9 Redut terhadap Remote Kontrol TV Anda

10 Spesifikasi Produk

AR — دليل التشغيل السريع

1 محتويات العلبة

2 وضع الجهاز الصوتي

3 توصيل الجهاز الصوتي

4 تشغيل النظام

5 التحكم بالجهاز الصوتي

6 اتصال البلوتوث

7 توصيل الأجهزة الصوتية

8 JBL SoundShift®

9 التحكم بجهاز التلفاز

10 المواصفات الخاصة بالمنتج

FR — Guide de démarrage rapide

1 Contenu de la boîte

2 Positionner votre barre de son

3 Branchement de votre barre de son

4 Allumer votre système

5 Commander votre barre de son

6 Connexion Bluetooth

7 Configuration de son surround sans fil

8 JBL SoundShift®

9 Réponse à la télécommande de votre téléviseur

10 Caractéristiques de produit

ES — Guía de inicio rápido

1 Contenido de la caja

2 Colocar la barra de sonido

3 Conectar la barra de sonido

4 Encender el sistema

5 Controlar la barra de sonido

6 Conexión Bluetooth

7 Configurar el sonido envolvente inalámbrico

8 JBL SoundShift®

9 Responder al control remoto del televisor

10 Especificaciones del producto

PT — Guia de Início Rápido

1 Conteúdo da caixa

2 Posicionamento da soundbar

3 Conectar a soundbar

4 Ligar o sistema

5 Controles da soundbar

6 Conexão Bluetooth

7 Configuração de som surround sem fio

8 JBL SoundShift®

9 Responda ao controle remoto da TV

10 Especificações do produto

DE — Kurzanleitung

1 Inhalt

2 Aufstellen der Soundbar

3 Anschließen der Soundbar

4 Einschalten des Systems

5 Steuern der Soundbar

6 Bluetooth-Verbindung

7 Einrichten des kabellosen Surround-Sounds

8 JBL SoundShift®

9 Steuerung mit Ihrer TV-Fernbedienung

10 Produktspezifikationen