

INSIGNIA™

24 in. Front Control Dishwasher

FEATURES

- 14 place settings to fit your whole family's dishes
- Four wash cycles (Heavy wash, Normal wash, 1 Hr wash, and Energy Saver wash) let you choose the ideal cycle
- Sanitize and High temperature options increase the water temperature
- Removable silverware basket fits at the front or side of the lower rack
- 4-hour delay lets you choose when your dishwasher runs
- Energy Star certification to reduce your energy usage
- Available in white or stainless steel to match your decor

INCLUDED

- Dishwasher
- Drain hose
- Silverware basket and side lids (2)
- Installation kit
- *User Guide*
- *Installation Guide*



NS-DWF2WH26 / NS-DWF2SS26

PRODUCT SPECIFICATIONS

Maximum capacity	14 place settings
Dimensions (H x W x D)	33 1/2 x 24 x 25 in. (85.09 x 60.96 x 63.5 cm) Depth with door open: 49.69 in. (126.2 cm)
Weight	Net: 56 lbs. (25.4 kg) Gross: 62 lbs. (28.12 kg)

Power requirements	120V~60Hz
Current	10A
Water pressure	Between 20 and 120 psi
Noise	52 dB
Energy Star certified	Yes