

- to prevent bubbles

ATTACHING YOUR SCREEN PROTECTOR

1 Remove your phone case (if needed).

with the dry cloth.

2 To prevent bubbles, clean your phone screen with the wet cloth, then remove moisture



3 Press the dust removal adhesive to your phone's screen repeatedly to remove any remaining debris.











protector cracks, we'll replace it free of charge. Just bring it into any Best Buy store. Before using your new product, please read these instructions to prevent any damage.





- Compatible with most cases















6 Align the top of the screen protector with

the alignment tool, then press it down from

7 Remove the alignment tool.



- 8 If there are bubbles, press them out toward the edges of the screen protector.
- **9** Reattach your phone case (if needed), then remove fingerprints with the polishing cloth.

7601 Penn Ave South, Richfield, MN 55423 U.S.A. ©2020 Best Buy. All rights reserved.













and Canada) or 01-800-926-3000 (Mexico) www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies

LIFETIME LIMITED WARRANTY

CONTACT INSIGNIA:

Distributed by Best Buy Purchasing, LLC

Visit www.insigniaproducts.com for details.





