



# ROKU®


Select Series  
4K TV



## What's included



Roku Select Series 4K TV



TV stands



65" model x 6 screws



85" model x 8 screws



43"/50"/55"/75" models  
x 4 screws

Stand screws




Roku TV Remote

## What you need



Phillips head  
screwdriver




Laptop or mobile  
phone for activation



Internet connection

## STEP 1: Set up your TV



### A Prepare a surface

Put a soft covering like a blanket down onto a clean, flat surface (make sure it's larger than the TV) and place the TV on it.

### B Attach the stands

Use a screwdriver and included screws to attach the stands.


### C Set TV upright

Place your TV on a stable, flat surface.


## Mounting your TV?

For instructions, skip these steps and visit [go.roku.com/TVmount](https://go.roku.com/TVmount)

**Note:** 85" model includes spacers installed in the VESA mount holes. Do not remove when wall mounting.



## STEP 2: Plug TV in and power your remote



### A Connect your TV


Plug your TV into a power outlet. It should turn on automatically. If it doesn't, press the power button.



### B Power your remote

See the remote features card on how to use your Roku TV remote.

## STEP 3: Activate your TV



### Connect your TV

Follow the instructions on your TV screen. Activate your TV by using your computer or smartphone to link a Roku account.



### IMPORTANT

Roku never charges for activation.

## Frequently asked questions

### Why do I need an internet connection?

You'll need an internet connection to set up your TV, stream your favorite channels and for automatic software updates.

### Why should I enter a payment method?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

# Get to know your TV

## Video connections

**HDMI** - Game consoles, DVD players

**Antenna/Cable** - Digital antenna, cable connection

## Audio connections


**HDMI eARC (recommended)** - AV receivers, soundbars

**Optical (S/PDIF)** - AV receivers, soundbars

## Other connections

**USB** - Flash drive

**Ethernet** - Wired internet connection





© 2025 Roku, Inc. All Rights Reserved.  
Roku, the Roku logo, and the purple  
d-pad and purple fabric tag designs are  
trademarks or registered trademarks of  
Roku, Inc.

Manufactured under license from Dolby Laboratories.  
Dolby, Dolby Audio, and the double-D symbol are  
registered trademarks of Dolby Laboratories Licensing  
Corporation. Confidential unpublished works. Copyright  
1992-2019 Dolby Laboratories. All rights reserved.

## Need help?

For setup help or  
support, visit or call

[go.roku.com/TV](https://go.roku.com/TV)

**1-816-272-8106**  
4:00 am - 10:00 pm PT

