


Thank you for your purchase!



HANGING HAMMOCK CHAIR WITH STAND



ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety WallStraps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Customer Service Email: CustomerExperience@belnick.com | Phone: 866-552-2810

SDA-AD608001-NAT-GG / SDA-AD608001-GY-GG

Have a Question/Concern?

Quality products and first-class customer service are the cornerstone of long-lasting consumer relationships. We strive toward excellence in all we do and want you to be completely satisfied with your purchase.

Please contact our exceptional Customer Experience Agents at the email address or phone number shown below to assist you with any product questions or issues before requesting a return.

We look forward to serving you in a friendly, efficient manner to resolve any issues you may have.

Customer Service Email: CustomerExperience@belnick.com

Customer Service Phone: 866-552-2810

Our Warranty Statement

This warranty covers manufacturing defects associated with your new product. The product is warranted from the original purchase date and to the original purchaser for normal usage, according to the below-referenced specifications and limitations.














- Non-moving metal parts are warranted for 5 years.
- Component parts including pneumatic cylinder, control mechanism, base and casters are warranted for 2 years.
- All other items are warranted for 1 year.

Normal usage means use in compliance with the restrictions and weight limits specified for the product. In the absence of product-specific restrictions and weight limits, normal usage means use for no more than forty hours per week by persons weighing 250 lbs. or less. Coverage terminates if the product is sold or otherwise transferred. Repairs made by parties other than Belnick also void this warranty.

This warranty will not cover: (1) labor, freight, or damage from misuse, abuse, negligence, alteration, assembly, installation, attachments, accident, vandalism, acts of nature or any other event beyond the control of Belnick; (2) tearing, scratching, scuffing, or blemishing of leather or fabric; (3) cosmetic damage that may result from normal usage; (4) damage attributable to use by persons exceeding specified weight limits or commercial use exceeding forty hours per week; or (5) rust or other damage caused by exposure to moisture. The user assumes all risk of injury resulting from use of this product. Liability for incidental or consequential damage is excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

.....


Parts

Part	Drawing	Description	QTY
A		Support connector	1
B		Chair	1
C		Support legs	4
D		Support pole	1
E		Screw M8*57	1
F		Screw M6*15	4
G		Nut	1
H		Wrench	1
I		Allen Wrench	1
J		Clevis Pin	1
K		Spring	1
L		Chain	1
M		Anchor Shackle	1

.....

Step 1


Attach Support Legs (Part C) to Support Connector (Part A) using (4) M6*15 Screws (Part F). Tighten using Allen Wrench (Part I). Bring to the upright position.



NOTE: Ensure Feet are facing down.


Step 2

Attach Support Pole (Part D) to Support Connector (Part A) using (1) M8*57 Screw (Part E) and (1) Nut (Part G). Tighten by placing the Wrench (Part H) on the Nut and using the Allen Wrench (Part I) to tighten the screw.



Step 3

Insert the Clevis Pin (Part J) into the top of the Support Pole. Insert one end of the Spring (Part K) into the Bolt then attach the end of the Chain (Part L) onto the other end of the Spring. Remove the bolt from the Anchor Shackle (Part M) and insert through the link in the Chain.



Step 4

Lift the Chair (Part B) and line the top U Bracket between the sides of the Anchor Shackle (Part M). Insert Bolt removed in Step 3 and securely tighten the nut using the Wrench and Allen Wrench as described in Step 2.

