

GR-4NP1

Cuisinart® Griddler

With five separate cooking options, the Cuisinart® Griddler® can handle everything from pancakes and sausages to grilled cheese to steaks, hamburgers, and panini. A floating cover and one set of reversible plates turn the Griddler® into a contact grill, panini press, full grill, full griddle, or half grill/half griddle. Dual temperature controls ensure everything is perfectly cooked every time on the removable dishwasher safe nonstick cooking plates for easy meals and clean up.

- Contact grill, panini press, full grill, full griddle, and half grill/half griddle
- Removable and reversible 11" x 9" dishwasher-safe nonstick cooking plates
- Cooking plates drain grease for healthy cooking
- Integrated drip tray collects grease and is easy to store
- Hinged floating cover adjusts to thickness of food
- Sturdy panini-style handle with hinged floating cover adjusts to thickness of food
- Selector knob to choose grill or griddle function
- Adjustable temperature controls for grill or griddle
- Red/green indicator lights for easy operation
- Brushed stainless steel housing
- Dishwasher-safe scraping tool for easy cleanup
- Instruction manual with gourmet recipes
- Limited 3-year warranty
- BPA Free

SPECIFICATIONS

Unit Carton:

UPC: 086279169297

Dimensions: 16.0"(L) x 8.9"(W) x 13.8"(H)

Weight: 13.2 lb.

Cubic Ft: 1.13

MASTER CARTON

Master Pack: 1

MBC: 10086279169294

Dimensions : 16.73"(L) x 9.57"(W) x

14.88"(H)

Weight: 11.85 lb.

Cubic Ft: 1.38

