



JLUAMPBRKTD

Drivers Side

JLUAMPBRKTP

Passenger Side

Under Seat Amplifier Mounting Bracket for 2018-2022 Jeep Wrangler JL & Gladiator

Attaching the Amplifier

Amplifier mounting holes are pre-drilled and threaded for select amplifiers listed below. Four M4x10 (3mm Allen) screws are supplied for mounting the amplifier. NOTE: When mounting different model amplifiers, it is recommended to temporarily install the bracket in the vehicle and determine a mounting position for the amplifier that will not interfere with the seat.

A - Phoenix Gold GX1200.6

B - Stinger SPX700X4

C - Phoenix Gold MX Series, All

D - Stinger SPX1000X5

E - Stinger SPX350X2

F - Phoenix Gold Z 8"


Active Bass Enclosure*

G - Phoenix Gold GX800.4, GX1200.1

H - AudioControl ACX-300.4

I - AudioControl ACX-600.1

**Mounting location F only available on Drivers Side (JLUAMPBRKTD)*



Installing the Mounting Bracket

The amplifier mounting bracket is placed under the rear seat legs and secured using the two rear seat bolts. To aid in the routing and connecting the amplifier wiring, it is recommended to remove all four seat bolts and tilt the seat backwards. Once all amplifier connections and settings are made, align the rear of the mounting plate with the rear seat bolt holes and reinstall the seat and seat bolts.

Replacement Mounting Screws:

Alloy Steel Socket Head Screw, Black-Oxide, M4 x 0.7 mm Thread, 10mm Long

McMaster-Carr # 91290A144

Limited Warranty

Stinger warrants this product to be free of defects in materials and workmanship for a period of one (1) years from the original date of purchase. This warranty is not transferable and applies only to the original purchaser from an authorized Stinger dealer in the United States of America only. Should service be necessary under this warranty for any reason due to manufacturing defect or malfunction, Stinger will (at its discretion), repair or replace the defective product with new or remanufactured product at no charge. Damage caused by the following is not covered under warranty: accident, misuse, abuse, product modification or neglect, failure to follow installation instructions, unauthorized repair attempts, misrepresentations by the seller. This warranty does not cover incidental or consequential damages and does not cover the cost of removing or reinstalling the unit(s). Cosmetic damage due to accident or normal wear and tear is not covered under warranty.

INTERNATIONAL WARRANTIES:

Products purchased outside the United States of America are covered only by that country's Authorized Stinger reseller and not by Stinger. Consumers needing service or warranty information for these products must contact that country's reseller for information.



Stinger is a Power Brand of AAMP Global
15500 Lightwave, Clearwater, Florida 33760
Phone: 888-228-5560

Technical Support

Phone: 727-592-5991

Email: support@stingerelectronics.com

Chat: stingerelectronics.com

QSG-JKUAMPBRKT REV 042822

© 2022 AAMP Global. All rights reserved.