



## MOTION SENSOR

This is the Kangaroo Motion Sensor. It's a simple security system that will alert you when there are threats to your fortress (or your garage).

Once set up, connected and armed, the system will monitor the space for motion and shoot an alert to your phone when it detects movement. Just connect it to your WiFi, stick it on your wall and relish the peace of mind.



## GET STARTED

Download the iOS or Android "Kangaroo Security" app, and have your WiFi password handy.

...that's it.


Once you've got the app, you'll be welcomed with a short setup walkthrough.



## HELPFUL HINTS



First you will make your account. Then you will set up your sensors. If you need help at any time, please contact customer service.

- During the setup process you will need to turn bluetooth ON. To do so, go to Settings on your phone, select  and turn it on.
- Once all of your devices are paired you may shut your bluetooth off.
- Read all of the instructions on the back of this manual before mounting your device(s).



## ARMING & DISARMING

The Kangaroo Motion Sensor is armed and disarmed using the Kangaroo Security app. When the system is armed, it will notify you when it detects motion. When it is disarmed, it will not.



## MOTION ALERTS: WHAT TO KNOW

You will receive a notification with the options to:

- Dismiss the alert & automatically Disarm the system.
- Call your Emergency Contact
- Call your local emergency services\*.

\*If you have signed up for Professional Monitoring, alerts that are not responded to will be forwarded to our UL-certified monitoring center. A member of their team will then alert your local authorities for dispatch.



## THE PLANS

### Kangaroo Basic

A great option for simple, straight-forward peace of mind. Receive notifications when sensors are triggered, invite as many users as you'd like and monitor multiple homes.

### Kangaroo Complete

A comprehensive security plan with all the Basic features, plus the support of a professional monitoring agency, SMS messages and voice notifications, Alexa and Google Home integration.



## Call

800-371-0097



## Chat

[heykangaroo.com/support](https://heykangaroo.com/support)




## Email

[support@heykangaroo.com](mailto:support@heykangaroo.com)



## FAQ


[heykangaroo.com/support](https://heykangaroo.com/support)



### DETECTION RANGE


If you're a numbers person, our Motion Sensor monitors up to a 15' distance and in an arc 60° to the left & right

If you're not, just know that one sensor can generally cover a room, but can't detect through walls or doors.



### WHERE TO PUT IT


- The Motion Sensor is made for indoor use only.
- Aim your motion sensor at likely entry points, except for windows.
- You can place your sensor next to windows and doors.
- You can place your sensor perpendicular to doors (with no glass panels), but not windows.



### WHERE NOT TO PUT IT

- Avoid placing behind doors or any kind of obstructions.
- Avoid placing near heaters, AC, and lamps as Motion Sensors detect changes in temperature.
- Don't place the sensor directly facing a window, as birds, cars or innocent pedestrians could trigger the sensor.
- If you have an acrobatic pet, avoid placing the Motion Sensor facing favorite perches of that pet.

False alarms suck. If you're getting them on the regular, try re-positioning based on the tips above. If you went by the book and are still getting them, contact us.



### HOW TO MOUNT


**No Pet**  
Select a spot **between 5'3" and 6'6"** off the floor and place with the **dome side-down**.

**Pet Parents**  
Select a spot **between 4'3" and 4'7"** off the floor and place with the **dome side-up**.

If your pet is above 2'4" tall, don't fret. You can mount your sensor just a bit higher than advised.



**Mounting**  
First use a light touch and make sure it's in the spot you want, then **push and hold firmly for 30 seconds**.



### BATTERIES

Your app will give you a heads up when your battery life is low.

To change them out, just slide the front of the Motion Sensor upwards.

Any AA batteries will do the trick, but we especially recommend lithium AA. Lithium batteries can last up to 2 years, whereas alkaline batteries have a lifespan of up to 6 months.

**Reset**  
Insert a small pin into the hole on the right side of the device and press for 10s.

**Troubleshooting: connectivity, pairing and power**

- Ensure the device's batteries are working.
- Make sure the yellow battery tab is removed and the batteries are aligned correctly.
- If you're having trouble pairing, try resetting.

**Specs**  
Detection Range: 120° field of view, up to 15ft away  
Size: 90mm x 39mm x 18mm  
Weight: 24g without batteries  
Battery: 2 x AA included  
Operating temperature: -5°C to 50°C

**System Requirements**  
WiFi 802.11 b/g/n, 2.4GHz (WEP, WPA, or WPA2 encryption) compatible router. Mobile device with iOS 10.0 and above | Android 5.0 and above. Active internet and cellular connections are required. Alarm monitoring service requires a Kangaroo Security subscription. For indoor use only.

**1-year worry-free warranty**  
[heykangaroo.com/warranty](http://heykangaroo.com/warranty)

# Motion Sensor Manual

