



Krane & Bauer



Krane & Bauer

Bass Series
USER MANUAL



**Bass
Driver**



Storm




**Bass
Hero**



Charging




- Please make sure your USB port is dry before charging.
- Use ONLY the enclosed USB-C charging cable and charger to prevent any damage. Use of any other cable will invalidate your warranty.
- Do not power on your headphone while charging.



	Flashing red once every 60 seconds	Low battery
	Steady red	Being charged
	Light off	Fully charged



Powering On/Off

Press and hold the power button for 3 seconds to power on/off.




Bluetooth Pairing

1. When powered off, press and hold the power button for 3 seconds until the LED flashes red and blue to enter the Bluetooth pairing mode.
2. Select your headphone on your device's Bluetooth list to connect.
3. Accept the Bluetooth pairing request on your device



	Flashing blue	Bluetooth pairing
	Steady blue (for 2 seconds)	Bluetooth connected





- Your Bass Series headphone can only play music on one mobile device at a time. To play from another connected device, pause the device that's currently active first
- Each time you power on your Bass Series headphone, it will automatically connect to your last successfully connected device if available within the Bluetooth range.

Button Controls

🎵		
Play/Pause	▶	Press
Next track	+	Press and hold for 1 second
Previous track	-	Press and hold for 1 second
Volume up/down	+/-	Press




Answer/End a call	📞	Press
Put the current call on hold and answer a new incoming call	▶	
Reject a call	▶	Press and hold for 1 second
Switch between held call and active call		

🎤		
Activate Siri or other voice assist software	▶	Press and hold for 1 second

AUX Mode

Play audio on an external device by plugging in a 3.5mm AUX cable.




- Plugging in an audio cable will automatically switch to AUX mode, and Bluetooth mode and ANC will turn off.



Reset

You might need to reset your headphone if you experience any connectivity problems or function issues.

Press and hold the power button and volume up button simultaneously for 5 seconds until the LED indicator flashes blue and red alternately twice.



Specifications

Specifications are subject to change without notice.

Input	5 V _{DC} 0.65 A
Charging time	2 hours
Playtime (music only)	40 hours
Driver size	40 mm × 2
Bluetooth range	15 m / 49.5 ft
Frequency response	20 Hz-20 kHz (Bluetooth) 16 Hz-40 kHz (AUX)
Impedance	16 Ω
Bluetooth version	V5.4





Krane & Bauer

