


# Pet Grooming Vacuum

**Model: LM2**



**ON-D80**

# Safety Warning

---

- **Read Before Use:** Before using the pet hair vacuum, read all safety and operating instructions.
- **Supervision:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Cord Management:** **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**
- Do not use to suck up water (for vacuum cleaners only).
- Please do not disassemble the product, the wrong assembly method may cause electric shock or fire. Please contact our company if maintenance is needed.
- Do not immerse in water for cleaning.
- The hose should be checked regularly and must not be used if damaged.
- Please keep the dust cup and filter clean.
- The appliance is only to be used with the power supply unit provided with the appliance.
- The plug must be removed from the socket-outlet before cleaning or maintaining the appliance.
- Please do not inhale flammable or combustible liquids such as gas o-line; In addition, please do not use the machine in or near an environment with flammable or combustible gases.
- Do not use it while smoking or working with other high-temperature items (matches, hot ash, etc.).
- Please do not put things into the opening or block the opening. Please unplug the power cord when you need to change the parts or conduct maintenance.
- Please do not use or keep it outdoors or in other wet places. Please do not use products with fragrance as the fragrance may contain flammable chemicals.

# Use Precautions

---

- Please do not operate with wet hands or unplug the power cord to avoid failure and electric shock.
- Please do not smoke or use other flammable material.
- Please do not use the machine in or near an environment with flammable or combustible gases.
- There may be a strange smell during the first use; however, it will not cause adverse effects on the body.
- When using this product for the first time, it will smell, but it will disappear after a while. Please understand, however, that if the scorching smell persists, stop using it immediately!
- Please keep the dust cup and filter clean; if the dust cup and filter are used while dirty, they may cause failure, and unexpected accidents may occur.
- During maintenance, turn off the power supply and unplug the power cord before proceeding.
- If the power is turned on for maintenance, it will cause electric shock, unexpected accidents, or injury.
- The product will stop working when the temperature rises abnormally; in case of abnormal heating of the motor, stop using it immediately. If the suction opening is blocked, please stop using it immediately. Take out the dust cup and clean the inlet and filter, then open it again after 60 minutes.
- Please be sure to install and use the filter; if you remove the filter, it will lead to failure.

# Contents

---

---

|                                     |           |
|-------------------------------------|-----------|
| <b>Tips for Use</b>                 | <b>01</b> |
| <b>Package List</b>                 | <b>02</b> |
| <b>Product Overview</b>             | <b>03</b> |
| <b>Product Technical Parameters</b> | <b>03</b> |
| <b>Operation Instructions</b>       | <b>04</b> |
| Accessory Combination               | 04        |
| Ready to Use                        | 04        |
| Use of Different Accessories        | 06        |
| Accessory and Power Mode            | 10        |
| <b>Maintenance</b>                  | <b>11</b> |
| How to Clean Dust Cup               | 11        |
| How to Clean Electric Clipper       | 12        |
| How to Clean HEPA                   | 13        |
| How to Clean the Sponge Filter      | 13        |
| <b>QA</b>                           | <b>14</b> |
| <b>Warranty</b>                     | <b>15</b> |

# Tips for Use

---

## **1. Familiarize your pet with the smell of the products.**

Place the vacuum cleaner and 6 grooming accessories where your pet can smell them and get used to them.

## **2. Let your pet touch 6 care accessories.**

Use the grooming accessories independently without connecting them to the vacuum cleaner or power supply. Try each grooming accessory on your pet until it is familiar and comfortable with the grooming accessory.

## **3. Place the vacuum cleaner farther away.**

The flexible hose is 1.5 m long. You can place the vacuum cleaner in another room and leave a gap for the hose.

## **4. Start with low speed.**


When you use the vacuum cleaner for the first time, we recommend you to start with low mode because it has the lowest noise level (<60 dB), which is easier for pets to accept and get used to. Once your pet gets used to it and feels less stressed, you can try to increase the suction power.

## **5. Reward in time.**


Appropriate petting and hugging can effectively alleviate pet anxiety and make them feel safe. Also reward them with treats and toys.

# Package List

---



Main Vacuum Machine x 1



Guide Combs x 6



Hose x 1



Pet Paw Trimmer X 1




Pet Nail Grinder x 1



Crevice Tool x 1




Cleaning Brush x 1




Deshedding Brush x 1



Pin Brush x 1





Electric Clipper x 1



Sponge Filter x 1  
(Extra free sponge filter, only need to install 1 piece when use)

# Product Overview

---



# Product Technical Parameters


---

|                   |   |
|-------------------|---|
| Input             | UK: 220V-240V~50Hz / US: 110V-130V~60Hz |
| Power             | 300W                                    |
| Hose Length       | 1.5M                                    |
| Dust Cup Capacity | 1.5L                                    |
| Product Size      | 302X220X130MM                           |
| Wire Length       | 2.5M                                    |
| Maximum Noise     | 60dB                                    |


# Operation Instructions

---

## 1. Install the Dust Cup



1. Align the snap-fit.



2. Press the dust cup down by your hand.





### NOTE


If the device has no suction or is very noisy, please reinstall the dust cup.

## 2. Ready to Use


1. Connect the accessory to the vacuum cleaner through the hose.




2. Insert the plug into the socket.




3. Turn on the switch and begin vacuuming.




4. Select the speed you need. We suggest starting with silence mode for first-time use.



5. Grooming Your Pet.



6. The hair sucked in can be thrown directly into the trash.



**! NOTE**

There are 3 Cleaning Modes: Silence Mode, Standard Mode, and Max Mode.


We suggest starting with the Silence Mode for first-time use as your pet will slowly get used to the noise.

# Use of Different Accessories

---


## 1. Daily Pin Brush

Used to clean floating hair and dander, making the hair more healthy, shiny, and soft.



## 2. De-shedding Brush

Used to remove the pet's long and unnecessary thick hair.




### **NOTE**

During use, pay attention to the cutting edge and position, do not use excessive force as it causes skin irritation.

### 3. Electric clipper

- ① Used to trim the pet's hair without leaving a mess as the hair will not fly around. While cutting, it suctions the cut hair!
- ② Rechargeable electric clipper can be separately used.



Use with vacuum or the clipper alone

#### **NOTE**

Remember to pay attention to the cutting edge and position, and do not use excessive force as it causes skin irritation.

### Tips for Guide Comb (used with Electric clipper)

- ① Choose the guide comb according to the length of pet hair you want to leave.
- ② The guide comb (3mm/6mm/9mm/12mm/18mm/23mm) is applicable for grooming different hair lengths.
- ③ You can put it in our storage bag to prevent it from getting lost.
  - The guide comb set is small; keep it stored properly when it is not in use.



3mm(1/8")



6mm(1/4")



9mm(3/8")



12mm(1/2")




18mm(3/4")




23mm(7/8")

Install the Guide Comb




Remove the Guide Comb




## How to Install the Blade

- Install the Blade



- Remove the Blade




### NOTE

- Don't Install the blade reverse, otherwise it will be broken.
- Please charge the clipper with the cord that came with it when the red light flashes.

## 4. Pet Paw Trimmer

Used to groom pet's paws, eyes, ears, face, and rump hair.




### NOTE

During use, pay attention to the cutting edge and position, do not use excessive force as it causes skin irritation.

## 5. Pet Nail Grinder

Used to groom your pet's nails.




### NOTE

Be careful on the soft parts of the pet's skin, and do not use excessive force as it causes skin irritation.


## 6. Cleaning Brush

Used to clean pet hair on clothes and furniture.



## 7. Crevice Tool

Used to clean hair on the furniture and hard-to-reach areas.



## Accessory and Power Mode

- The following chart is for advice only, please choose accessories and modes according to your needs!



| Accessory   | Power Mode  |   |  |
|---|---|---|--|
|   | Silence Mode  | Standard Mode   | Max Mode   |
|    | Cleans fallen hair from the sofa, corner, or other hard-to-reach areas.     | Cleans the fallen hair from the sofa, corner, or other hard-to-reach areas. | Deep cleaning of stubborn dust. <b>(Recommended)</b> |
|    | Cleans surface dust and makes the hair smooth.                              | Airflow massage makes the hair glossy. <b>(Recommended)</b>                 | Deep cleaning to remove dead hair.                   |
|    | Trim styling, handling hairstyle detail. <b>(Recommended)</b>               | With soft suction to trim and suck removed hair.                            | Don't recommend.                                     |
|    | Soft suction power to clean the pet hair on clothes.                        | Deep clean hair on your clothes.  | Strong suction power. <b>(Recommended)</b>           |
|  | Remove loose hair.  | With soft suction to de-shed pet hair. <b>(Recommended)</b>                 | Suction to de-shed pet hair.                         |
|  | For dog and cat paws, eyes, ears, face, and rump hair. <b>(Recommended)</b> | With soft suction to trim and suck removed hair.                            | Don't recommend.                                     |
|  | Polish your pet's nails by rounding them out. <b>(Recommended)</b>          | With soft suction to trim pet's nails.                                      | Don't recommend.                                     |

# Care and Maintenance



---

## Cleaning the Dust Cup


1. Press the remove button and take off the dust cup.



2. Press the release button and pour out the hair.




3. Assemble the dust cup according to the arrow direction.




- If the removed dust cup is cleaned with water or a wet cloth, be sure to install it after the dust cup is completely dry. Otherwise, it will damage the motor.
- Please take dust cup lightly. If it drops, it will be damaged easily.
- If you have any problems with the cup, please contact us on Amazon or via email:[support@oneisall.com](mailto:support@oneisall.com)

# Cleaning the Electric Clipper


1. Remove the blade by turning it counterclockwise.



2. Vacuum out and clean the debris from the blade and the clipper.




3. Place oil on the blade.




**Note:** Our products do not include a bottle oil, you can maintain the cutter blade with your home machine lubricant

## Cleaning the HEPA & Sponge Filter


1. Remove the dust cup and remove the HEPA & sponge filter.



2. Tap it or clean it with brush. Don't wash it with water.



3. Place the HEPA & sponge filter back into the machine.



## NOTE

The product is equipped with voltage protection device. If you hear a "didi" sound when you press the switch, and the gear lights are all flashing, it means that the machine voltage is not consistent. Please check your voltage. If you have any problems, please contact us at any time with our email [support@oneisall.com](mailto:support@oneisall.com)

## Troubleshooting

| Problems                                       | Possible Causes                           | Solutions   |
|--|---|---|
| Can not be turned on                           | Plug is not inserted well                 | Reinsert the plug   |
|  | Switch is not turned on                   | Press switch button to turn it on                               |
| Weak suction                                   | Flexible hose is clogged                  | Clean flexible hose and suction mouth                           |
|  | Dust cup is too full                      | Empty dust cup  |
|  | Filter is dirty                           | Clean filter  |
| The pet clipper heats up during use            | Internal parts of the machine have debris | Please remove the blade, wash and oil                           |
| The hose is broken                             | Accidental damage                         | The hose is detachable and can be stored in the bag we provided |
|  | Bitten by pets at home                    |   |
| Whistle-like noise when the machine is running | The dust cup snap is not aligned          | Please check whether the dust cup is installed                  |

- If the above solutions do not solve the problem, please stop using the product, and contact our customer support: [support@oneisall.com](mailto:support@oneisall.com)

# Contact Us

---

## WE ARE READY TO HELP

Oneisall offers a standard **2-year** warranty. If you have any issues with your Oneisall product, please do not hesitate to contact us. Be sure to include your proof of purchase, model number, and any relevant photos or videos in your message to expedite the process. Our Oneisall support team is available 7 days a week and will respond to your inquiry within **24 hours**. Thank you for choosing Oneisall.

Please note that the Oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty also does not cover consumable parts such as blades, guards, filters, brushes, and similar items. These parts may require regular replacement or maintenance.

✉ [support@oneisall.com](mailto:support@oneisall.com)

📞 +1 877-522-8578 (US) **Mon-Fri** 8am-5pm(PST)

🌐 [www.oneisall.com](http://www.oneisall.com)



Guide video



@Oneisall Official

# GPSR Product information

---

## UK REP

Name: APEX CE SPECIALISTS LIMITED  
Add: 6f East Union Street, Manchester, England, M16 9AE  
Contact: Wells  
Tel : +441616371080  
E-Mail: Info@apex-ce.com

## EC REP

Name : Apex CE Specialists GmbH  
Add : Grafenberger Allee 277-287,40237 Düsseldorf,DE  
Contact Person: Wells Yan  
Tel: +353212066339  
E-Mail: Info@apex-ce.de

## GPSR-Manufacturer info:

Business Name: Shenzhenbenfendianzishangwuyouxiangongsi  
Manufacturer's Address: CN, 518000, Guangdong Sheng, Shenzhen,  
Longhua District, Minxin Community Bishui Longting Building 6 Unit, 7B  
Tel: +86 185 6587 6424  
E-Mail: topservice4u@hotmail.com

Product Name: Pet Grooming Vacuum  
Brand: oneisall  
Product Model: LM2  
Input: US 110V-130V~60Hz / UK 220V-240V~50Hz  
Power: 300W



Made in China



Any problems you have, please contact us :  
[support@oneisall.com](mailto:support@oneisall.com)



Scan the QR-Code to get the product  
installation video and join us to get  
more prizes

ON-D80