


For product installation videos and more, visit: weboost.com/install

Register your Signal Booster now!

... weboost

A Wilson Electronics Brand

Complete the two easy steps to register your booster and receive premium customer service, special offers and more!



Need help? Visit photoregister.com/help or text HELP to 71403.

GDE000228_Rev01_09.22.20

weboost.com



Installation **Overview**




Drive Reach RV Cell Signal Booster

STEP 1: Mount Outside Antenna & Route Cable



Determine where you want the Outside Antenna on your RV. **Mount the Outside Antenna** to a ladder or pole so that the entire Outside Antenna is above the roof line of the RV. **Route 25' RG-6 cable** from inside RV to Outside Antenna.

NOTE: L-Bracket Pole Mount and hardware is provided. If installing with Spring, the Side Exit Adapter must be used.



ladder rail

Side Exit


Adapter

Spring (optional)


L-Bracket Mount & hardware



After routing the RG-6 Cable into the RV, connect the cable to the Outside Antenna.











STEP 4: Booster Location & Connect Cables

Find a location to place the **Drive Reach Booster** and secure it with provided bracket. **Connect cable from Outside Antenna** to labeled booster port and **connect cable from Inside Antenna** to labeled booster port.



STEP 5: Connect Power Supply To Booster

Connect the power supply cord to the end of the booster, labeled " **——**", and connect into a 110V wall plug. Enjoy your boosted signal!



Refer to Installation Guide for Detailed Instructions.