

## Troubleshooting

### The image is not square

- Check that the projector's lens is parallel to your projection surface and that your projection surface is flat.

### No sound

- Check the volume control on your source device to ensure the volume is turned up.
- Check the volume control on the projector to ensure the volume is turned up.
- If you are using an adapter, verify that the adapter supports audio.
- Check that the HDMI cable is fully plugged into the HDMI port.

### No Signal Message

- Check that you are using the required cable and/or adapter.
- If you are using a digital AV adapter, check that the adapter is an authentic Apple adapter and is compatible with your model phone or tablet.
- If you are connecting via USB-C, check that you are using the USB-C video cable that came with the projector – this cable is labeled “USB-C Video Connector.” Some USB-C cables do not support video.
- If you are connected to a laptop or computer, check your computer display settings to ensure a multiple display option is selected (such as “duplicate these displays”).
- Check that your source device supports HDMI video out or USB-C video out.

### Projector will not power on, or stay powered on

- Check the battery life of the projector. If one or fewer lights are illuminated, charge the battery with the USB – C cable and your MacBook USB – C power adapter, or the AC Power Adapter included with the projector.

### The image is blurry

- Press the motorized focus buttons on the remote, or side of the projector to focus the image.
- Check that the surface you are projecting on is smooth and non-reflective.

## Learn More

To learn more about your Miroir HD Pro Projector and its operations, to review specs, and find answers to frequently asked questions, please visit: [www.miroirusa.com](http://www.miroirusa.com)


# miroir

## Ultra Pro Projector

© 2018 Miroir USA, LLC. All rights reserved. Miroir and the Miroir logo are owned by Miroir USA, LLC. All other trademarks are the property of their respective owners. Miroir USA, LLC assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

## Quick Start Guide

# Your Miroir Ultra Pro Projector




- A Battery Indicator Lights** - Lights flash in turn as the device charges. The battery is fully charged when all the lights illuminate and no longer flash.
- B Lens Cover/Power** - Slide lense cover to turn device on.
- C Projection Lens**
- D Audio Out (3.5mm)** - (Optional) Connect an external speaker or headphones.
- E HDMI Video Input** - Connect an HDMI cable to a device that supports HDMI video output.
- F USB Power Output** - Connect a USB power cable to provide power to a HDMI streaming stick or to charge a smartphone battery. Cannot be used for video input.
- G USB-C Charge/Video Input** - Connect the supplied USB-C Charge/Video cable to a device that supports USB-C video output, or connect the supplied USB-C Charge/Video cable to your MacBook Pro AC Adapter to charge the projector's internal battery. Note: Projector battery will not charge and project simultaneously via a USB-C connection. Fully charge the battery before first use (approximately 4-5 hours).
- H Reset Button** - Press to reset projector.
- I DC Power Input**
- J Source Input Button** - Press to change input source.
- K Focus Mode** - Press button then use volume +/- buttons to adjust.
- L Volume Controls** - Increase/decrease the volume output of the projector.
- M Rubber Foot Pads** - Provides stability and proper airflow to cooling vents.
- N Cooling Vent**
- O Tripod Mount** - Will fit a standard sized tripod screw. Tripod not included.

## Included in the Box:

- USB-C Charge/Video Cable
- HDMI Cable
- Micro HDMI Adapter
- Quick Start Guide
- RF Remote
- AC Adapter/Charger
- Projector Drawstring Pouch


# Your Miroir Ultra Pro Projector Remote Control



- A Power**
- B Invert Image**
- C Eco Power On/Off**
- D Motorized Focus**
- E USB-C Video Input Select**
- F Volume Control**
- G HDMI 1 Input Select**
- H HDMI 2 Input Select**


## Connect Your Device Using HDMI

To connect your Apple device to a Miroir projector, you will need an Apple Digital AV Adapter (sold separately) and an HDMI cable (included in the box).



## Connect Your MacBook Pro and MacBook Using USB-C

To connect your MacBook to a Miroir projector, you will need a USB-C Video Cable (included in the box).



**IMPORTANT!** Not all USB - C cables will support video. The USB-C cable that comes with the projector will support video and charging.