



PACKAGE




1. One Pair of Bluetooth Headset
2. Three Sets of Ear Tips and Earhooks
3. One USB Charging Cable

FUNCTIONS




CHARGING




To charge the headset, plug in the USB cable into the headset Micro-USB charging port. The headset LED will be red when charging, and will turn white when the headset is fully charged.

POWER



Power on: Press the control button for 4 seconds, and the headset LED indicator flashes white to indicate the device is on.
Power off: Press the control button for 4 seconds, and the headset LED indicator flashes red to indicate the device is off.

PAIRING



1. Press the control button for 6 seconds, and the headset LED indicator will be blinking white and red alternately.
2. Select **"Rowkin Pulse"** on your mobile device to connect.
3. Once paired, the headset LED indicator will be flashing white.

CONTROLS

- Answer call: Press the control button once to answer the incoming call.
- End call: Press the control button once to end a call.
- Reject call: Press the control button for 2 seconds to reject the incoming call.
- Play music: Press the control button once to play music.
- Pause music: Press the control button once to pause music.
- Previous track: Press the volume down button (-) for 1 second for previous track.
- Next track: Press the volume up button (+) for 1 second for next track.
- Activate voice command: Double press the control button.

Note: Please ensure your mobile device supports voice command function for this feature.

WARRANTY

Limited Six (6) Months Warranty with proof of purchase. Exempt from warranty are limited-life consumable components subject to normal wear and tear, e.g. ear tips, batteries and other accessories.

For warranty and support, please visit www.rowkin.com or email us at support@rowkin.com

The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc. All other trademarks and trade names are those of their respective owners.

© 2016 ROWKIN. ALL RIGHTS RESERVED.

V: 11042016

SAFETY INFORMATION

Use Responsibly

Do not use headset when it is unsafe to do so: while operating a vehicle, crossing the street, or during any activity or in an environment where your full attention to your surroundings is required.

It's dangerous to drive while wearing the headset and in many places illegal because it decreases your chances of hearing life-saving sounds outside of your vehicle, such as another car's horn and emergency vehicle sirens. Please avoid wearing our headset while driving.

Listen Responsibly

To avoid hearing damage, make sure that the volume on your music player is turned down before connecting your headset. After placing the headset in/on your ear, gradually turn up the volume until you reach a comfortable listening level. Noise levels are measured in decibels (dB); exposure to any noise at or above 85 dB can cause gradual hearing loss. Monitor your use; hearing loss is function of loudness versus time. The louder it is, the less time you can be exposed to it. The softer it is, the more time you can listen to it.

To prevent possible hearing damage, do not listen at high volume levels for long periods.



TROUBLESHOOTING

PROBLEM	PROBABLE CAUSE	SOLUTION
Sound breaks up	Headset is too far away from the source device; Interference between the headset and the source device; The human body may interfere and weaken signal in some conditions.	Keep source device close and in direct view of the headset.
The other party on the call can't hear my voice	Environment is too noisy; Headset is covered during the call, for example, by hair or hands.	Remove anything covering the headset; Speak louder and call in a quiet environment.

If you need additional support assistance, please visit www.rowkin.com or email us at support@rowkin.com.



For the best Bluetooth connection, keep source device in direct view of the headset. The human body may interfere and weaken signal in some conditions.

SPECIFICATIONS

Dimension:

1.46" (L) x 0.85" (W) x 1.2" (H)
(37.3 x 21.7 x 30.5mm)

Weight:

0.46oz (13.2g)

Battery type:

Rechargeable lithium-ion polymer battery

Battery input:

5V/100mA

Battery capacity:

100mAh

Charging time:

<90 minutes

Standby time (power on):

about 12 hours

Standby time (power off):

about 80 days

Music/Talk time:

up to 4 hours

Frequency response:

20Hz-20KHz

Bluetooth version:

4.1

Bluetooth profiles:

HFP, HSP, AVRCP, A2DP

Audio enhancements:

Noise reduction and echo cancellation

STATEMENTS

FCC and IC Compliance Statement

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) this device must accept any interference received, including interference that may cause undesired operation.

EU Compliance Statement

Rowkin hereby declares that this wireless device is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive.

Caution Statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

WARNING: Do not expose this product to liquid or excessive heat.

Disposal Information

The symbol indicates that this product and/or battery should not be disposed of with household waste. When you decide to dispose of this product and/or its battery, do so in accordance with local environmental laws and guidelines.



Wireless Bluetooth Stereo Headphones

www.rowkin.com