




### Package contents



Backpack



6' USB Charge Cable




Controller grips (2)

- *Quick Setup Guide*

### Features


- The PS4 Backpack contains storage for the PS4 system, games, and accessories.

### Backpack




Before using your new product, please read these instructions to prevent any damage

## Silicon grips



Use caution when inserting the DUALSHOCK® controller into the silicone grip to avoid damage to the controller.

## 6' USB Charge Cable



## 90-day limited warranty

Visit [www.rocketfishproducts.com](http://www.rocketfishproducts.com) for details.

## Contact Rocketfish:

For customer support, call 1-800-620-2790 (U.S. and Canada) or 01-800-926-3010 (Mexico)

[www.rocketfishproducts.com](http://www.rocketfishproducts.com)

Manufactured and distributed under license by Sony Computer Entertainment America LLC.

“PS”, “PlayStation” and “DUALSHOCK” are registered trademarks of Sony Computer Entertainment Inc.

“PS4” is a trademark of the same company.

ROCKETFISH is a registered trademark of BBY Solutions, Inc. Registered in some countries.

Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2013 BBY Solutions, Inc. All Rights Reserved.