

LED / LCD Screen Cleaning Kit

Quick Setup Guide

BE-HCL301 / BE-HCL301-C

BEST BUY
essentialsTM

Before using your new product, please read these instructions to prevent any damage.

Package contents

- Cleaning solution
- *Quick Setup Guide*
- Microfiber cloth


Features

- Works with a variety of LCD and LED screens, including smartphones, tablets, TVs, and monitors
- WARNING:** Not recommended for camera lenses or OLED screens. See the documentation that came with these products for cleaning information.
- Features an alcohol- and ammonia-free anti-drip solution
 - Includes an 8 × 6 in. (20 × 16 cm) washable microfiber cloth that stores inside the cap
 - Minimizes streaks across your device screen
 - Built and backed by Best Buy


Cleaning your screens

- 1 Turn off the screen and allow to cool.
- 2 Spray the cleaning solution onto the microfiber cloth until lightly damp.

Note: Do not apply the liquid cleaning solution directly to the LCD or LED screen.



- 3 Gently wipe the screen with the damp side of the microfiber cloth to remove smudges and fingerprints.



- 4 Dry the screen completely using the dry side of the microfiber cloth or let the screen sit for several minutes to make sure that the screen is dry before using again.
- 5 Let the microfiber cloth dry, then store it inside the cleaning solution cap.

Specifications

- **Microfiber cloth dimensions:**
8 × 6 in. (20 × 16 cm)
- **Cleaning solution:**
Water and sodium laureth sulfate. Does not include alcohol and ammonia
- **Microfiber cloth material:**
80% polyester and 20% nylon

One-year limited warranty

Visit www.bestbuy.com/bestbuyessentials for details.

Contact Best Buy essentials

For customer service, call 866-597-8427 (U.S. and Canada)

www.bestbuy.com/bestbuyessentials

Best Buy essentials is a trademark of Best Buy and its affiliated companies.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2021 Best Buy. All rights reserved.