

Before using your new product, please read these instructions to prevent any damage.

USB 2.0 4-Port Hub DX-U24H41

Package contents


- USB 2.0 4-Port Hub
- AC adapter 5V/2A
- USB cable
- *Quick Setup Guide*

System requirements

- Computer with a USB 2.0 or USB3.0 port
- Latest version of Windows® 8, Windows® 7, Windows Vista®, or Windows® XP; or Mac OS X 10.4 or later
- Minimum free disk space: 600MB recommended

Features


- Complies with USB 2.0
- Compatible with USB 1.1 devices
- Supports transfer rates of up to 480Mbps
- Adds four USB 2.0 ports to your USB 2.0 enabled computer
- Blue LED power indicator
- Supports hot-swappable and Plug & Play capability
- Supports over-current protection at USB host port




Installing your hub

Note: When you connect your hub to a computer, the computer detects your hub and automatically installs the driver.

- 1 Connect the smaller end of the USB cable to the upstream port on the rear of the hub and connect the larger end of the USB cable to an open USB port on your computer.



- 2 Plug the AC power adapter into your hub's DC jack and into a power outlet.
 - 3 Connect your USB devices into your hub.
- Note:** Do not disconnect from your computer or USB device during data transfer. Doing so may corrupt your data or damage your devices.



One-year limited warranty

For complete warranty, visit
www.dynexproducts.com.

Contact Dynex:

For customer service, call 1-800-305-2204
(U.S. and Canada) or 01-800-926-3020
(Mexico)
www.dynexproducts.com

DYNEX is a registered trademark of BBY Solutions, Inc.
Registered in some countries.
Distributed by Best Buy Purchasing, LLC, 7601 Penn
Ave South, Richfield, MN 55423 U.S.A.
©2013 BBY Solutions, Inc. All Rights Reserved.