




# 18" Oscillating Wall Mounted Fan

OWNER'S MANUAL



Model: ILG8IN18X

**PLEASE READ AND SAVE  
THESE INSTRUCTIONS**

# Important Safety Instructions

**CAUTION:** Read and follow all instructions before operating fan. Do not use fan if any part is damaged or missing.

**WARNING:** To reduce the risk of electrical shock, do not use this fan with any solid state speed control device.

## INSTRUCTIONS FOR SAFE OPERATION



- Never insert fingers or any other objects through the grill guard when fan is in operation.
- Always mount fan with the supplied bracket.
- Unplug the fan before servicing, such as assembly, removing guards for cleaning , installing or replacing Fuses.
- Do not use with an extension cord.
- Do not place fan or any parts near an open flame, stovetop, cooking or other heat-generating appliances.
- This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.

## ASSEMBLY INSTRUCTIONS

### **Fan Head Assembly:**


1. Remove the fan head parts from the box.
2. Place the motor on a flat level surface with the motor shaft facing up.
3. Loosen the rear guard locker from the motor, secure the rear guard to the motor by tightening the rear guard locker.

rear guard locker



4. Align the blade shaft sleeve with the stopper of the motor shaft and install it, then tighten with the fan blade locker.

stopper



5. Place front guard on rear guard, adjust the position ring to make the guards in place and tighten the screw of position ring. Then install the decorative cover to the screw.



Decorative cover

## Wall Mounting

Install the mounting plate to the wall with screws (included), then hang on the fan.

**NOTE:** The arrow on the mounting plate should be downward.

Fan can also be mounted to concrete wall with the appropriate fastener.



Mounting Plate



## OPERATING INSTRUCTIONS



### **To adjust airflow position:**

Pull the swing chain, the fan will keep on swinging. Pull the chain again to stop swinging.

### **Speed Control:**

Pull the speed chain to switch for low, medium, high speed, or turn off the fan.

It is normal for the motor to feel warm to the touch after continuous operation. This fan features thermal protection that will automatically shut the fan off should it overheat for any reason. If this happens, immediately unplug the fan from the outlet.

## REPLACING PLUG FUSE

When the fuse in the power cord blows, please replace the fuse by following steps:

1. Disconnect the plug from the wall outlet. Grasp plug and remove from the

receptacle or other outlet device. Do not unplug by pulling on cord.

2. Open fuse cover - Slide open the fuse access cover on top of attachment plug towards blades, as shown in Figure 1.
3. Remove the fuse carefully using a flat head screwdriver, as shown in Figure 2.
4. Risk of fire. Replace the fuse only with 2.5 Amp, 125 Volt fuse, as shown in Figure 3. (You may purchase a replacement fuse from a local hardware store).
5. Close fuse cover - Slide the fuse access cover on top of attachment plug, as shown in Figure 4.
6. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.



**Figure 1**



**Figure 2**



**Figure 3**



**Figure 4**

## **CLEANING INSTRUCTIONS**

Unplug the fan from the outlet before cleaning. After servicing, all parts (including grills and blades) must be reinstalled or remounted as previously installed. Use soft damp cloth then wipe with dry cloth. Do not use harmful cleaners. Do not bend the blades. The motor bearings are permanently sealed and do not require additional lubrication.

## Product Specifications

**Model#:** ILG8IN18X

**Voltage:** 120V, 60Hz

**Current:** 0.6A

**Power:** 70W

## WARRANTY

This fan comes with a ONE-YEAR LIMITED COMPONENT WARRANTY.

If your fan does not appear to be working properly, please contact our service center by calling 1-800-317-1688. Prior to your call, we encourage you to visit our website [www.ilivingusa.com](http://www.ilivingusa.com) for troubleshooting tips and service instructions if needed.

## Warranty Information

Register your product at our website:



Or visit [iLivingUSA.com/register-product](http://iLivingUSA.com/register-product)

## Feedback

Love it? Help us make the product more for you.



Let us know with a customer review.

Please visit: <https://www.amazon.com/review/review-your-purchases#>

At iLiving USA, we are committed to bringing top quality products to our customers.

iLIVING USA  
860 Mahler Road,  
Burlingame, CA 94010  
Tel: 1-800-317-1688  
Email: [service@ilivingusa.com](mailto:service@ilivingusa.com)



Like us on Facebook: <https://www.facebook.com/ilivingusa/>



Follow us on Twitter: @iLIVINGUSA

Check out our website: [www.ilivingusa.com](http://www.ilivingusa.com)