

MRC-WLP43



**Wireless Backup Camera
& Color Monitor Kit**
User Manual



ECHOMASTER



MRC-WLP43
Wireless Backup Camera
& Color Monitor Kit

Introduction

Thanks for purchasing the EchoMaster Wireless Backup Camera and Color Monitor Kit.

EchoMaster Camera & Monitor Kits are designed to improve safety by providing high quality images from camera inputs. This may help to improve vehicle maneuvering capabilities by displaying blind spots or areas not normally visible to the driver.

Please ensure you read and understand all aspects of this manual before fitting or using your EchoMaster products.

For installation video, please visit EchoMaster.com

Box Contents

- ▶ Wireless camera (with built-in transmitter)
- ▶ 4.3" Wireless color monitor (with built-in receiver)
- ▶ Mounting bracket arm
- ▶ Dual 2.4A USB CLA charger (provides power to the monitor, as well as an extra USB port to charge any device that is USB chargeable, up to 2.4A).
- ▶ 3.2ft USB to micro-USB cable to power monitor
- ▶ Install accessories (T-Taps, zip ties)

Key Features

- ▶ Color monitor that can be mounted to your dash or windshield
- ▶ Adjustable monitor mounting arm
- ▶ Camera with 120° viewing angle
- ▶ Adjustable vertical camera angle
- ▶ System automatically activates when car is in reverse
- ▶ Additional USB port for charging a device

MRC-WLP43
Wireless Backup Camera
& Color Monitor Kit



Installing the Camera

Step 1

Remove the screws that hold the license plate to the vehicle and remove the license plate.



Step 2

Find an opening (or drill a small hole) to feed the camera cable into the vehicle.



Step 3

Position the camera mounting bracket behind the license plate.

Insert the screws to hold the camera and license plate in place.



Step 4

The camera angle should be adjusted to a horizontal position relative to the ground to provide the best view behind the vehicle.

To adjust the camera angle, tilt the camera up or down to one of the five positions for your optimal viewing.



⚠ PLEASE NOTE

These instructions are only a general guide. If more assistance is needed, please consult with a professional installer.




MRC-WLP43

Wireless Backup Camera
& Color Monitor Kit

Installing the Camera - continued

Step 5


Insert each of the wire ends from the camera cable into the male T-Taps. Crimp the T-Tap onto the wire to secure its position.



Red Wire >> 12V / power
(when vehicle is shifted to reverse gear)
Black Wire >> Ground.

Step 6

Locate your reverse light wires. Position the female T-Taps onto each wire. Close the T-Tap onto the wire of the reverse light. You can use regular pliers for this.




Make sure its connection is secure.

Step 7

A voltmeter may be necessary to determine polarity, + and -.

Connect the T-Taps together.



MRC-WLP43

Wireless Backup Camera
& Color Monitor Kit

Setting Up the Monitor

Step 1

Slide the arm onto the back of the monitor. Press on to the dash or windshield.

Push lever towards the base to secure in place.



Step 2

Fine tune the monitor's position and make sure to tighten the knobs on the bracket when finished.



Step 3

Connect the USB cable to the USB power adaptor and insert it into the vehicle's lighter / 12v socket.



to order additional car chargers and power cables, please visit iSimple.com



MRC-WLP43

Wireless Backup Camera
& Color Monitor Kit

Setting Up the Monitor - continued

Step 4

The blue LED will turn on once powered.

When in reverse, the monitor will display the camera view instantly.



Adjusting Monitor Settings

Step 1

Press the menu button to open the settings screen when vehicle is in reverse gear. When not in reverse gear, pressing the menu button will enter time and date set-up mode.

Step 2

Press the arrow keys to change settings and press the menu button to scroll to next setting.

When vehicle is not in reverse gear, the following settings can be changed:

Time and Date

When vehicle is in reverse gear, the following settings can be changed:

Brightness
Language

Contrast
Reset to defaults

Color



MRC-WLP43

Wireless Backup Camera
& Color Monitor Kit

Camera	
Sensor	CMOS
LEDs	No
Illumination	1 Lux
Viewing Angle	120°
Mirror Image	Yes
Normal Image	No
Water/Debris-Proof	IP66
Audio	No
Power Supply	DC12-24V 1A
Current	<300 mA
Operating Temp	14°F - 140°F/-10°C - 60°C
Dimensions - mm (in)	66 (2.6) x 36 (1.4) x 38 (1.5)
System	NTSC
TV Lines	480
Resolution (HxV)	680 x 480

Built-in Transmitter	
Frequency	2.4G ± 0.3
RF Transmission Distance	495 ft
Operating Temp	14°F - 140°F / -10°C - 60°C

Monitor	
Screen Size	4.3"
Aspect Ratio	16:9
Power Supply	DC 5V 1A
Resolution	640x480
Luminance	250 nits
Contrast	400
TV Format	NTSC
OSD Languages	Yes
Video Inputs	1 input
Audio Inputs	0
Triggers	1
Current	300mA
Operating Temp	14°F - 140°F / -10°C - 60°C
Parking Guidelines	Yes
Connection Type	Micro-USB
Dimensions - mm (in)	120 (4.72) x 25 (1.0) x 20 (0.78)

For installation video, please visit <http://echomaster.com/>



email - support@aampglobal.com (US)
tel - 800-477-2267



EchoMaster is a Power Brand of AAMP Global.
EchoMaster.com

REV080117