

# Chair Assembly Instructions

Estimated Assembly


Time in Minutes

☆ <15   ★ <45   ☆ 60+

Your chair comes packaged in one box.

**DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.**


Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.




Parts List		Hardware List	
<b>A</b> 1 x Seat		* <b>E</b> 8 x Bolts with Lock washers & Flat Washers	5/16" x 50mm 5/16" 5/16"
<b>B</b> 1 x Back		* <b>F</b> 1 x Hex Key	
* <b>C</b> 4 x Legs		* Replaceable Parts	1/4" x 100mm
<b>D</b> 1 x Dust Cover		Hardware bag can be found under the seat.	

## Assembly


Step 1



Step 2




Step 3




Step 4

Line up brackets. Push down hard on the back. Make sure bracket locks into place on both sides. There should be no gaps between the back and the seat.



Step 5



Your style may differ from images. Care for your furniture by periodically tightening all bolts using the included hex key.

**CAUTION:** Tighten all components securely before use. Failure to do so may result in personal injury.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

Customer Support: 866-238-0531  
 Mon-Fri 8:00am - 4:30pm CST  
 customerservice@furniturequestions.com

