

TOZO® EN

7.2 Charging the earbuds

*The charging box is not in the charging state, the charging box charges the earbuds.

Earbuds in the charging box	Flashing once to show the charging box battery level.
Earbuds in charging	Eed light keeps on.
Earbuds fully charged	Red light off, blue light on for 5 seconds and then off.

8.0 Specification

Name	A2
Transmission distance	10M
Rated power	3mW
Earbuds battery capacity	3.8V/30mAh
Charging box battery capacity	3.7V/315mAh
Playing Time	4.5 hours
Charging time of the charging case	2 hours
Charging port	Type C
Size of the earbud	32.2*22.8*23.6 mm
Size of the charging box	70*49*31 mm

05

TOZO® EN

9.0 EU Battery Regulation



This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product shall not be treated as household waste. Instead, please separate battery(ies) from other types of waste and recycle it (them) through your local recycling system to protect environment and health. (When Cd is more than 20ppm or Pb is more than 40ppm, the chemical symbol of the excess substance shall be marked under the separate collection symbol) For more detailed information about recycling of this battery(ies), please contact your local authority or the shop where you purchased the product or battery(ies).

10.0 FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

06

TOZO® EN

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

11.0 ISED Compliance Statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
 (1) This device may not cause interference.
 (2) This device must accept any interference, including interference that may cause undesired operation of the device.
 L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

12.0 CE-DOC

Hereby, [Manufacturer] declares that the radio equipment type [Model No.] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.tozostore.com

07

TOZO® EN

FAQ:

1.Q: Failed charging of the charging case.
 A: Make sure the charging cable is intact and plugged in properly.

2.Q: Two devices named "TOZO-A2" are found.
 A: Delete both names and search again.

3.Q: Sound is unclear.
 A: Increase the volume slowly on your phone and earbuds and keep them close to each other.

4.Q: Why can not hear voice?
 A: 1. Ensure both earbuds have been turned on.
 2. Turn up the phone's volume to maximum.
 3. Try to tap the touch control once to play music.

SPECIAL REMINDER:

Wipe the hardware contacts of the headset and charging box when the headset is not charging.

Note:

If your problem is not answered above, please contact us via email, we will respond within 24 hours.

Email: info@tozostore.com

Battery Warning!

This product is built in lithium battery. Do not expose the product to strong sunlight, fire or throw it into the fire to avoid explosion.




A2 TRUE WIRELESS STEREO User Manual

08

TOZO® EN


1.0 Product description



Indicator Lights of the Charging Case

2.0 Wearing steps

Step 1: Ensure the eartip facing downwards, then place the earbuds into your ears.
 Step 2: Rotate the earbuds back to the auricle side to fit snugly.



01

TOZO® EN

3.0 Operation of earbuds

3.1 How to pair

- In first use, take earbuds out of the charging box and the earbuds will power on and automatically connect to each other. Open the bluetooth device, search [TOZO - A2] and select the connection. (voice prompt : connected)
- Non first used, the earbuds will auto connect back to the last pairing device when turning on.



3.2 Power on/off

Power on :

- Tap and hold the Touch Control Pannel of both earbuds for more than 3 seconds.
- Take earbuds out from case to power on automatically.

Power off :

- Touch the Control Buttons 5 seconds to turn it off while earbuds is not playing.
- The earbuds will turn off automatically after being disconnected for more than 5 minutes.
- Place earbuds back in the case to power off automatically.

3.3 Reset

If your earbuds accidentally only get one earbud to work, or fail to pair. Please reset it.

- Delete Bluetooth records
- Delete all [TOZO A2] Bluetooth records on your phone, then turn off the Bluetooth.

02

TOZO® EN

- Press and hold earbuds about 5s
Pick up two earbuds from charging case and wear them, then press and hold both earbuds, then release fingers after hearing "Power Off".
- Press and hold the both earbuds again for 8s
Press and hold the both earbuds again, release fingers after hearing "PTP pairing", reset completed.
- Put earbuds back into case and take out again, two earbuds will flash red and blue alternately, turn on the Bluetooth to connect again.



4.0 Music Operation

Double tap the "L" to skip to the previous song	2X	Tap and hold "R" to increase the volume	Hold
Double tap the "R" to skip to the next song	2X	Tap and hold the "L" to decrease the volume	Hold
Tap the L/R touch area to play or pause music	1X		

03

TOZO® EN

5.0 Call control



Tap L or R touch area to answer the call or it will answer the call automatically.
 Hold L or R 2S the sensing area to hang up the call.
 Hold L or R 2S the sensing area to reject the call.

6.0 Voice assistant



When using single or both earbuds, triple-tap the L or R earbud to wake up the Voice assistant with a "Beep" sound.

7.0 Charging

7.1 Charging the charging case

- When power of the charging case is insufficient, put the earbuds into the charging case, the first light on charging box will flash for 4s and then go out;
- Plug in the charging box and charge with USB interface charger, four white lights are on when fully charged.

0-25%	The first light flashes.
25-50%	The first light keeps on constantly, and the second light flashes.
50-75%	The first two lights keep on constantly, and the third light flashes.
75-100%	The first three lights keep on constantly, and the fourth light flashes.
Full charged	Charging box with four lights on.

04



Scan the QR code to get the manual in other languages

Thank you for purchasing the TOZO authentic product. For more latest products, parts and accessories, please visit: www.tozostore.com
 For any assistance please contact Email: info@tozostore.com

FC RoHS CE

01