

BATTERY OPERATED COIN SORTER



DCB-175B

Thank you for purchasing the Royal Sovereign Battery Operated Coin Sorter, DCB-175B. This manual will provide you with safety information, instructions for optimal use, and proper care and maintenance for your product. Please read this manual carefully before operating.

CONTENTS

SAFETY INSTRUCTIONS	2
BOX CONTENTS	3
PRODUCT VIEW.....	3
QUICK START GUIDE.....	4
PRODUCT OPERATION.....	5
COIN TUBE QUANTITY.....	5
COIN WRAPPER AVAILABILITY.....	6
SPECIFICATIONS	6
WARRANTY	7

SAFETY INSTRUCTIONS

When using this machine follow these safety precautions to reduce risk of fire, electric shock, or injury.

CAUTION

1. Do not operate the machine for any purpose other than its intended use.
2. When using the machine, place it on a sturdy and level work place.
3. Do not allow any other materials to enter except coins.
4. Do not alter the construction or design.
5. Do not mix old and new batteries.
6. Do not mix alkaline, standard, or rechargeable batteries.
7. Take out the batteries when it is not in use for a long period of time.
8. Do not immerse the machine in water or permit liquid to get inside the machine.

Read & Fully Understand This Owner's Manual Before Using This Machine.

BOX CONTENTS



Coin Sorter



Coin Tubes

PRODUCT VIEW



QUICK START GUIDE

1. Open the battery compartment (located on the bottom of the unit) and insert two “C” batteries.
2. Insert preformed coin wrappers (sold separately) into the corresponding tubes (A).
3. Switch the power to the ON position (located on the side of the unit) (B).
4. Place loose change into the hopper (C).



A



B



C

For More Detailed Instructions, Go To Page 5

PRODUCT OPERATION

1. Open the battery compartment on the bottom of the unit and insert two “C” batteries.
2. Place the machine on a level work surface.
3. Insert preformed coin wrappers (sold separately) into the corresponding coin tubes.
4. Flip the power switch to the ON position to start the machine.
5. Gradually insert coins into the coin hopper. Coins will begin to sort into the corresponding coin tubes.
6. When a coin tube is full, turn the machine off, and remove the full coin wrapper. To remove filled wrappers, pull up on the exposed edge of the plastic tube and remove. Then, push the coin wrapper up from the bottom of the tube and fold the edges of the wrapper.
7. Place a new wrapper into the coin tube and return the tube back in place. Flip the power switch back on to continue counting.
8. After sorting is finished, flip the power switch to the OFF position.

COIN TUBE QUANTITY

COIN	QUANTITY	DOLLAR AMOUNT
Pennies	50	\$0.50
Nickels	40	\$2.00
Dimes	50	\$5.00
Quarters	40	\$10.00

COIN WRAPPER AVAILABILITY

Royal Sovereign offers a wide variety of coin wrappers to suit your coin sorting needs. Royal Sovereign coin wrappers come in sizes of 112, 504, and 1,008. Within each size, Royal Sovereign offers packs that are assorted and by denomination (Quarter, Penny, Nickel, and Dime). Royal Sovereign coin wrappers come preformed and crimped on one end to provide easy and hassle free coin wrapping.



SPECIFICATIONS

MODEL	DCB-175B
Dimensions	5.70" W x 5.90" D x 8.20" H
Speed	120 Coins per Minute
Motor Type	DC Motor
Power Consumption	3W
Power Supply	Two "C" Batteries
Weight	2.20 lbs.

ONE YEAR LIMITED WARRANTY

Royal Sovereign International, Inc. warrants this product to be free from defects in material and workmanship for a period of one (1) year. This warranty is extended to the original purchaser only.

This warranty only covers products that are properly installed, properly maintained, and properly operated in accordance with the instructions provided. This limited warranty does not cover any failures or operating difficulties due to normal wear and tear, accident, abuse, misuse, alteration, misapplication, improper installation, or improper maintenance and service by you or any third party.

Returned product will not be accepted without a Return Authorization number. To request a Return Authorization number, please visit us at www.royalsovereign.com. All transportation costs for the return of damaged product or parts will be the responsibility of the purchaser. Return defective product, in original packaging, to the address below.

Royal Sovereign International, Inc. requires reasonable proof of your date of purchase from an authorized retailer or distributor. Therefore, you should keep your receipt, invoice, or canceled check from the original purchase. The limited warranty shall be limited to the repair or replacement of parts which prove defective under normal use and service within the warranty period.

Royal Sovereign International, Inc. (and its affiliated companies) SHALL HAVE NO LIABILITY WHATSOEVER TO PURCHASER OR ANY THIRD PARTY FOR ANY SPECIAL, INDIRECT, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above exclusion and limitations may not apply to you.

ROYAL SOVEREIGN INTERNATIONAL, INC.

2 Volvo Dr., Rockleigh, NJ 07647 USA

TEL: +1) 800-397-1025

Email: info@royalsovereign.com