




Chair Assembly Instructions

Your chair comes packaged in one box.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.



Parts List		Hardware List	
A 1 x Left Arm		F 1 x Seat Cushion	
B 1 x Front Rail		G 1 x Back Cushion	
C 1 x Right Arm		Hardware List	
D 1 x Back Frame		* H 4 x Wood Buttons	
E 1 x Seat Frame		* I 2 x Wood Dowels	
			M8 x 30mm
		* J 4 x Bolts	
			M6 x 50mm
		* K 4 x Screws	
			M4 x 25mm
		* L 1 x Long Hex Key	
			M4 x 100mm
		* M 1 x Short Hex Key	
			M5 x 70mm
		* N 4 x Bolts (pre-installed)	
			M8 x 18mm
		Not included 1 x Philips Screwdriver or Power Screwdriver (low torque)	
		* Replaceable Parts	


Assembly

Step 1




Assembly


Step 2




Step 3



Step 4



Step 5



Your style may differ from images. Care for your furniture by periodically tightening all bolts using the included hex key.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531
Mon-Fri 8:00am - 4:30pm CST
customerservice@furniturequestions.com