

Chair and Ottoman Assembly Instructions


Estimated Assembly Time in Minutes

☆ <15 ★ <45 ☆ 60+

Your chair and ottoman comes packaged in one box.



DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.




Parts List		Hardware List	
A 1 x Back		F 1 x Seat Cushion	
B 1 x Left Arm		6 x Legs	
C 1 x Right Arm		* G (2 x Chair Front Legs 4 x Ottoman Legs)	
D 1 x Seat Deck		* H 2 x Chair Back Legs	
E 1 x Front Rail		* I 8 x Washers	
		J 1 x Ottoman	
		* K 4 x Bolts (pre-installed) M6 x 25mm	
		* L 1 x Hex Key M5 x 110mm	
		* Replaceable Parts	

Assembly




Assembly


Step 3



Step 4




Step 5




Remove the protective fabric from the seat cushion and seat deck.

Step 6

Ottoman x 1



Step 7



OPTIONAL



G or **H**
Adjust each leg by inserting a washer (I) to make it even and level with the floor.

Your style may differ from images. Care for your furniture by periodically tightening all legs and periodically tightening all bolts using the included hex key.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531
Mon-Fri 8:00am - 4:30pm CST
customerservice@furniturequestions.com