

4 ft. Full-Color LED Tape Light

Quick Setup Guide

BE-LED4RGB19

BEST BUY
essentialsTM

Before using your new product, please read these instructions to prevent any damage.

WARNING: Unroll before use. Never plug in the LED lights when rolled up, as this can result in product damage or a fire.


Package contents

- LED tape light
- Double-sided tape
- Quick Setup Guide

Features

- Produces custom lighting with 20 color options
- Attaches to TVs, cabinets, and other objects
- Adjust the brightness level with a multi-step dimmer
- Cuts to whatever length is needed
- Reduces eye strain from TVs and monitors
- Powered by USB
- Built and backed by Best Buy


Using your tape light



Shortening your tape light

- Use a pair of scissors to cut on a cut line. Cut lines are about 1.3 in. (3.3 cm) apart.

Warning: Do not cut the silver solder markings. Only cut in the center of the copper-colored pads, as shown.



Attaching your lights

- 1 Peel the adhesive backing off the lights, then adhere the lights where you want them.
- 2 **Optional:** Attach the double-sided tape to the back of the light control, then adhere it where you want it.

Notes:




- Make sure that the tape light is unrolled, otherwise it can damage the tape light or cause a fire.
- Every surface is different, and additional adhesive may be used if the LED tape detaches from the surface. Small pieces of clear tape can be used.

Connecting to power

- Place the tape light where you want it, then connect the USB connector to your TV, computer, or other USB power source.

Adjusting the lights

Note: If you turn off or unplug your tape light, it will remember your last brightness and color settings.


- Press  (POWER) to turn the tape light on and off.
- Press  (COLOR) repeatedly to change the color combination. There are 20 available colors including white.
- Press  (BRIGHT) repeatedly to adjust the brightness. There are eight light levels.

Specifications

- **Input:** 5V DC, 1A
- **USB power supply (not included):** 5V DC, 0.5A minimum (1A or more recommended)
- **Length:** 4 ft. (1.2 m)

Troubleshooting

LEDs will not turn on.

- Press the power button to make sure that your light is turned on, then press  (BRIGHT) to increase the brightness.
- Make sure that your lights are connected to a working USB port or power outlet. If connected to a computer, turn on your computer.

LEDs flicker or turn on and off.

- Make sure that your lights are plugged into a working power outlet or USB port. Try plugging into a different power source.
- Make sure that the cable is not damaged.

Safety Information

- To avoid damage to the light strip, do not sharply twist or bend the light strip 90° or more.
- Do not cut the silver solder markings. Only cut in the center of the copper-colored pads.
- Do not plug in your lights when they are coiled. This can generate excess heat which can damage the product or connected device.

One-year limited warranty

Visit www.bestbuy.com/bestbuyessentials for details.

Contact Best Buy Essentials

For customer service, call 866-597-8427 (U.S. and Canada)

www.bestbuy.com/bestbuyessentials

Best Buy Essentials is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2021 Best Buy. All rights reserved.