

Cabinet Assembly Instructions








Your cabinet comes packaged in one box .

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.



Parts List


A 1 x Top Panel 	B 1 x Left Side Panel 	C 1 x Right Side Panel 	D 2 x Middle Panels 
E 1 x Shelf Panel 	F 1 x Bottom Panel 	G 1 x Left Door Panel 	H 1 x Right Door Panel 
I 4 x Legs 			

Hardware List


J 1 x Hex Key  M4 x 60mm	K 4 x Floor Protectors 	L 1 x Phillips Screwdriver or Power Screwdriver (Not included) 	M 12 x Cams 
N 12 x Cam Dowels 	O 12 x Screws  M3.5 x 16mm	P 2 x Magnetic Catch 	Q 2 x Catch Plate with 4 x Small Screws (M3 x 12mm) 
R 18 x Bolts  M6 x 35mm			* Replaceable Parts

Assembly


Step 1




Step 2




Step 3




Step 4



Step 5




Step 6




*use pre-drilled holes

Assembly


Step 7 Remove and discard the plastic sleeve from the leg bolt.




Step 8



Step 9



Step 10



It is highly recommended to use coasters or mats beneath hot pans, plates, and glassware to protect the surfaces and finish of your furniture.

Your cabinet style may differ from images. Care for your furniture by periodically tightening all legs.

About your furniture piece:

- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531
Mon-Fri 8:00am - 4:30pm CST
customerservice@furniturequestions.com