

INSIGNIA™

QUICK SETUP GUIDE

2-Pack Silicone Seals for Insignia Pressure Cookers

NS-MCRG6S9-2

If the seals inside your pressure cooker are damaged, have an odor, or do not create a tight seal, you need to replace the seals. Seals help maintain the correct pressure.

PACKAGE CONTENTS


- Silicone Seals (2)
- *Quick Setup Guide*

FEATURES


- Two swappable seals prevent savory and sweet odors from mixing
- BPA free and FDA approved for safe contact with your food
- Works with Insignia and select other pressure cookers with a 9-inch (22.8 cm) diameter

REPLACING THE SEAL

- 1 Remove the old seal by carefully pulling it up section by section.



- 2 Install the new seal by pressing it down section by section into the seal rack. You can install the seal with either side facing up.



Before each use:

- Make sure that the seal is well seated in the seal rack. If necessary, carefully shift the seal clockwise or counter-clockwise inside the seal rack to improve sealing.
- Make sure that the anti-block shield is correctly mounted on the steam release pipe.
- Do not use force when pulling the seal. Using force can cause deformation and lead to a poor seal between the lid and the cooker body.
- Do not use a seal with cracks, cuts, or other damage.
- Keep the seal clean to avoid odor. Wash the seal in warm soapy water or in a dishwasher to remove odor. If washing does not get rid of the odor, replace the seal.

SPECIFICATIONS

Dimensions (H x W): 0.7 x 9.4 in. (1.8 x 23.8 cm)

Weight: 0.12 lbs. (55 g)

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2018 Best Buy. All rights reserved
Made in China