

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Any other trademarks are for reference purposes.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à [arlo.com/docs](https://www.arlo.com/docs).

(If this product is sold in Canada, you can access this document in Canadian French at [arlo.com/docs](https://www.arlo.com/docs).)

For regulatory compliance information including the EU Declaration of Conformity and where to find e-label information for US FCC & Industry Canada, visit www.arlo.com/about/regulatory/.



Arlo Technologies Intl. Ltd.
Ground Floor, Building 3
University Technology Centre
Curraheen Road, Cork, T12 EF21
Ireland

Arlo Technologies, Inc.
2200 Faraday Avenue, Suite 150
Carlsbad, CA 92008 USA

August 2021



201-50599-01



Security Sign

You can set up your Security Sign and stake it in the ground or you can wall-mount your sign.

What's in the box



Arlo Security Sign
with Top Rod



Center
Rod



Bottom
Rod



Connectors



Optional
Wall Mount
Screw Kit



CAUTION: Sharp Edges. Watch your fingers.

The rod edges are sharp and contact may result in injury. Do not pick up the stake rod by the sharp end. During use, direct the sharp edges away from you and others. Keep out of reach of children.

Set up your Security Sign


1

Tighten the screws to secure the sign to the top rod.




2

Assemble the rod using the connectors.



3

Select an outdoor location and push the bottom rod into the ground.



Wall-mount your Security Sign

1. Unscrew the sign from the top rod.
2. Use the wall mount screw kit to mount the sign on your wall or fence.

Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and:

- How-to videos
- Troubleshooting tips
- Additional support resources