


ROKU™

Wire-free
Video
Doorbell &
Chime

**Quick Start
Guide**





For the best experience, charge your doorbell before setup

To charge doorbell: Plug one end of the charging cable into the micro USB port on the back of your doorbell. Connect the other end to a standard USB power adaptor (like your phone charger).





What's included




- A** Roku Wire-free Video Doorbell
- B** Roku Enhanced Chime
- C** USB charging cable
- D** Screw back plate
- E** Back plate
- F** Corner kit

- G** Wire caps (x3)
- H** Short screws (x3)
- I** Extension wires (x2)
- J** T8 screwdriver
- K** Long screws (x3)
- L** Plastic anchors (x3)
- M** Adhesive strip
- N** Jump wire

What you'll need


- Your smartphone

A**B****C****D****E****F****G****H**




- 1** Light sensor
- 2** Lens
- 3** Motion sensor


- 4** Microphone
- 5** Doorbell button
- 6** Speaker



**Doorbell
FRONT**



**Doorbell
BACK**



Chime

7 Micro USB charging port

8 Power button

9 Screw terminals

10 Status light


11 Setup button

12 Speaker

Let's get started

STEP 1: Download the Roku Smart Home app

Scan the QR code below to download the Roku Smart Home app on your smartphone. Sign in with your Roku account or create one.



Message & data rates may apply.

Continue on back 

STEP 2: Install your doorbell & chime

In the Roku Smart Home app, tap the “+” button, then “**Add Device**” to find “**Wire-free Video Doorbell.**” Follow the instructions to install your camera and complete setup.

Recommended location

Install your doorbell less than 6.5 feet above ground level.



What's that light mean?

Doorbell	State
WHITE - Solid	Charging
BLUE - Solid	Fully charged

Chime	State
RED - Flashing	Connecting to doorbell
YELLOW - Flashing	Waiting for connections
BLUE - Flashing	Connecting to network
BLUE - Solid	Connected



More features are waiting

Unlock the full potential
of your doorbell with a
Roku Smart Home Subscription.

Learn more at
go.roku.com/rokusmarthome

Need help?



Setup
videos



Common
questions



Tips and
tricks

Visit go.roku.com/doorbells

Roku

© 2024 Roku, Inc. All rights reserved. Roku, the Roku logo, Roku Smart Home, and the Roku Smart Home logo are the trademarks or registered trademarks of Roku, Inc.



4100001063_01