

USER'S MANUAL

Island Pool Float with Canopy NP10725

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

Please read all instructions carefully and keep it for future reference.

Warnings:

Attention: For home use only.

Attention: The product is not suitable for the children aged 8 years or younger

Danger: Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.

Danger: Lack of attachment may cause a risk of tipping or falling hazard.

General Warnings:

⚠ The product must be installed and used under the supervision of an adult.

⚠ Read through each step carefully and follow the proper order.

⚠ Remove all packaging, separate and count all parts and hardware.

⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.

⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.

⚠ Please check and maintain it regularly, and the most important part needs to be suspended, fixed, or anchored to the ground.

SAFETY NOTICE

Read important information before using this product.

Warning:

Always keep it away from sharp objects that could cause damage.

Set it on a clean, smooth, flat surface. Keep free from heated surfaces, stones etc.

Not to be used by children except under adult supervision. Adult assembly required.

Remove shoes before entering and do not take any metal objects inside.

Clean with a damp cloth.

Do not over-inflate, around 30~40 minutes by electric pump, which may vary by different inflation pumps.


Safety symbols on the product



Warning symbol



No protection against drowning



Operating pressure permitted: max. 0.44 psi



Prohibition sign



Do not use in breaking waves



Do not use in white water



Do not use in offshore wind



Do not use in offshore currents




Not for children aged 8 years or younger



Mandatory sign



Always read the instructions for use first



Fully inflate the air chambers. Please note the order: 1 / 2 / 3



Only to be used by confident swimmers



Max. number of users: 2 adults / 0 children



Maximum load: 440 lbs



Always supervise children in the water



Safe distance from the shore: 98.5 ft




Device is stable when floating (applicable)



Device requires ability to balance (not applicable)


1




Inflating

1. Roll out/open up the product completely and check for any damages.
2. Inflate all air chambers in the order specified on the product using a suitable hand or foot pump until the product is completely filled with air and stretched out. You must still be able to push in the case slightly with your thumb.
3. Carefully close the valve and check if any air is leaking out.
4. Push the valves into the product after inflating it.

2



3



Insert the rods into the roof.



Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich AU office: Truganina

Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US: cs.us@costway.com

UK: cs.uk@costway.com

AU: cs.au@costway.com