

MSC-400

Cuisinart® 4 Quart 3-in-1 Cook Central Multicooker

The Cuisinart® 4-Quart 3-in-1 Cook Central® is a compact and convenient way to make family dinners every day. Brown your ingredients right in the pot before slow cooking for delicious dishes with the flavors turned up. Take control of your meals with preset functions to brown/sauté, slow cook, and steam foods for endless variety of dishes. The Cook Central® makes family favorites easy, including chili, pulled pork, macaroni and cheese, and even oatmeal for healthy breakfasts. The 24-hour timer and automatic Keep Warm function ensures your delicious meal will be waiting for your family to come home.

- 3 fully programmable cooking functions:
- Slow Cook on high, low, simmer, or warm for up to 24 hours
- Brown/Sauté with temperatures up to 400°F
- Steam for up to 90 minutes
- Includes automatic Keep Warm feature
- One touch switches modes when recipe calls for combination cooking
- Removable 4-quart nonstick aluminum cooking pot
- Extra-large blue backlit LCD display with easy-to-read time and temperature settings
- Glass lid with cool-touch handle for clear view and comfortable handling
- Dishwasher-safe removable parts for effortless cleanup
- Steaming rack included
- Limited 3-year warranty
- BPA free

SPECIFICATIONS

Unit Carton:

UPC: 086279059192

Dimensions: 9.6"(L) x 19.1"(W) x 13.65"(H)

Weight: 14.2 lb.

Cubic Ft: 1.45

MASTER CARTON

Master Pack: 1

MBC:

Dimensions : 19.75"(L) x 14.4"(W) x 10.7"(H)

Weight: 13.5 lb.

Cubic Ft: 1.62



Cuisinart®