




30" GAS FREESTANDING SELF CLEAN RANGE

MODELS:

AGR6603SFB0 (Black)
AGR6603SFW0 (White)
AGR6603SFS0 (Stainless)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10545337	Instructions, Installation
	W10866294	Guide, Use & Care
	W10873899	Tech Sheet
	W10873901	Diagram, Wiring
	9762761	Tips, Safe Cooking (English)
	W10065852	Tips, Safe Cooking (French)
2		Set, Burner Cap
	W10225167	Black
3	W10515452	Assembly, Burner (12K)
		(Left Front)
	W10515454	Assembly, Burner (9.5K)
		(Right Front and Left Rear)
	W10515453	Assembly, Burner (6K)
		(Right Rear)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Cooktop
	8272253	Black
	8272251	White
5		Panel, Manifold
	8523855	Black
	8523854	White
6		Knob, Control
	W10844795	Black
	W10844794	White
7		Kit, Grate
	W10682667	Black
8	3400701	Screw
9	3196557	Screw
10	8523249	Bracket, Manifold
11	W10306542	Bracket, Anti-Tip
12	7101P485-60	Screw, Anti-Tip Kit
13	W10515459	Electrode

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	8273062	Screw
		Following Parts Not Illustrated
	W10842520	Harness, Main
	W10753750	Harness, Bake/Broil
	W10809927	Harness, Cooktop
	W10519920	Harness, DSI Ground
	3196896	Clip, Wire
	3196520	Clip, Wire
	W10334923	Clip, Gas Wiring
	313438	Clip, Harness
	3196173	Screw
	3196696	Clip, Harness
	3196174	Screw
	7111P017-60	Clamp, Wire


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10516123	Bracket, Console Mounting	12	3196178	Screw
	W10184437	Black (Left)	6	8523412	Bracket, Rear Cooktop	13	W10516463	Bracket, DSI
	W10184438	Black (Right)	7	W10198745	Cover, Upper	14	W10695491	Bracket, Control
	W10184433	White (Left)	8	W10192841	Shield, Heat	15	8053505	Shield, Heat
	W10184434	White (Right)	9	W10184370	Cover, Back	16	W10797001	Bracket, Ignitor
2	W10110488	Module, Spark	10	3196169	Screw			
3		Panel, Console	11		Control, Range			
	W10834160	Black		W10845611	Black			
	W10834159	White		W10837804	White			
4	W10511278	Module, Spark DSI						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W10279614	Valve, Gas	19	3400016	Screw
2	W10295996	Bracket, Saddle Valve			(Left Front, Right Front & Left Rear)	20	W10170508	Orifice (9.5K)
3	W10474154	Assembly, Orifice Holder (12K) (Left Front)		W10247744	Valve, Gas (Right Rear)			(Right Front and Left Rear)
	W10473929	Assembly, Orifice Holder (9.5K) (Left Rear)	9	3196176	Screw		W10178934	Orifice (12K) (Left Front)
	W10474169	Assembly, Orifice Holder (9.5K) (Right Front)	10	3196265	Screw		W10170506	Orifice (5K) (Right Rear)
	W10474163	Assembly, Orifice Holder (6K) (Right Rear)	11	3196385	Screw	21	W10137062	Spreader, Flame (Broiler)
4	W10215439	Tubing (Manifold to Regulator)	12	8054078	Burner, Broiler			Following Parts Not Illustrated
5	W10812380	Harness, Switch	13	W10184491	Spreader, Flame (Oven)		W10170531	Spuds, LP Gas
6	W10224921	Bracket, Aegis	14	9758078	Burner, Bake		W10566537	Kit, LP Bake and Broil
7	W10812381	Assembly, Manifold	15	W10602001	Regulator			
			16		Ignitor			
				W10333842	Electrode, Broil			
				9758079	Electrode, Bake			
			17	W10420040	Tube, Broiler Supply			
			18	W10592836	Fitting, Broiler			

CHASSIS PARTS




CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10153186	Box, Flue
2	8272747	Shield, Flue
3	8273036	Box-Burner, Gas Sealed
4		Panel, Side
	W10162245	Black
	W10575396	White
5	3196178	Screw
6		Frame, Front (Not Serviced)
7	W10341186	Assembly, Front Foot
8	W10058460	Foot, Leveling
9	3195097	Bottom, Oven
10	W10586204	Sensor
11	8053967	Baffle, Burner Oven
12	8053969	Shield, Heat

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	8053968	Shield, Lower
14	W10390008	Assembly, Base Rail (Left)
	W10390007	Assembly, Base Rail (Right)
15	W10362924	Screw
16	W10031780	Screw
17	W10224919	Back, Main
18	W10658354	Seal, Door
19	W10435470	Brace, Main Back
20	9761449	Retainer, Insulation (Left)
	9761448	Retainer, Insulation (Right)
21	W10137382	Clip, Panel
22	W10624590	Cord, Power
23	W10289077	Receiver, Hinge
24	W10379120	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
25	W10454648	Assembly, Light
26	311255	Bulb, Oven Light
27	3196560	Screw
28	W10674705	Glide, Drawer Front
		INSULATION
	8524099	Insulation, Wrap
	W10180437	Insulation, Back
29	W10627802	Switch, Door
30	9761013	Assembly, Door Latch (Front)
31	9757239	Rod, Door Switch
32	W10078370	Rod, Push Latch
33	W10107820	Assembly, Door Latch (Rear)
34	3196169	Screw


DRAWER AND BROILER PARTS



DRAWER AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10268578	Rack, Oven	4		Rivet, Push	7	3196165	Screw
2	W10688022	Drawer, Storage		3196813	Black	8		Panel, Drawer Front
3	W10462911	Bracket, Mounting		3196814	White		W10330069	Stainless
		(For Black & White Models)	5		Panel, Drawer Front			
	W10462909	Bracket, Mounting		8053338	Black			
		(For Stainless Model Only)		8053336	White			
			6	W10674708	Glide, Drawer Rear			

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top Vent
	W10310922	Black
	W10310920	White
2	W10200660	Screw
3		Handle, Door
	W10323589	Black
	W10323588	White
	W10144883	Stainless
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7		Badge
	W10846751	Black
	W10846752	Stainless
8		Glass Assembly, Outer Door
	W10890951	Stainless
9	9761357	Retainer, Insulation
10	W10299227	Hinge, Door (Passive)
	W10299224	Hinge, Active (With Spring)
11		Glass, Outer Door
	W10886896	Black
	W10851723	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Trim, Door Side
	W10746436	Black (Left)
	W10746435	Black (Right)
	8523172	White (Left)
	8523166	White (Right)
13	W10327235	Screw
14	3196165	Screw
15	W10544179	Strap, Door
16	W10031780	Screw
17		Trim, Bottom
	8523177	Black
	8523175	White
18	W10316950	Frame, Glass

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	241430	Aluminum Foil
	4396923	Broiler Pan and Grid