





**PLAY**<sup>®</sup>

FOR ADULTS

[www.Voice.Gift](http://www.Voice.Gift)




**Imagine being able to attach a voice memo just like a sticky note... to anything!** Well, now you can. Just write a number from 1 - 999 and write it on the margin of a book or an album, stick it on a trail marker, or next to a piece of art or a collectible. Then record your thoughts, insights, comments, directions, guidance or reminiscence onto the PLAY device using the same number. Whenever that number is entered, your audio note will play. It's as easy as Press to Record, Press to Play!



**INCLUDES:**

- Lithium-ion rechargeable battery

# 1 Record It



Make sure the PLAY device is fully charged. Slide the selector switch into REC position and using the keypad enter a number between 1 - 999. Then press the Forward button (II>).

Wait for the beep and start speaking into the device to record your message. The LED light will illuminate while you are recording. Press the Forward button again when you have completed your recording. Repeat for additional messages, entering a different number for each message.


## 2 Program It

(Optional)



In addition to using the USB cable to charge your PLAY, you can also use it to back up your files. You can even transfer .mp3 files from your computer on to your PLAY... Just rename the files with the number (1-999) that you want to use to trigger playback. Once you are finished recording all your audio on to one PLAY device, you can back them up on your computer and copy them to other PLAY devices for friends and family.

### 3 Play, Skip, Go Back.




To play your audio files, slide the selector switch into the PLAY position. Input the number of the message you wish to play and press the Forward button (||>). To pause, press the Forward button again. To skip to the next message, press the Forward button twice. To return to the previous message, press the Back button (<||) twice. Using the forward button to go to the next message is a great way to listen to numbered messages recorded in sequence.

# 4 Clip It, Hang It, Turn It Up.



PLAY was created to add the soundtrack of your life and things. Insert the provided clip into the side of the device to attach to the back cover of any photo book, scrapbook or journal. Press the orange release button to remove the clip. Thread the strap through the anchor on the bottom of the device, put on your headphones, adjust the volume and your journey begins!



Check out a how-to video and discover how others are using their VoiceGift PLAY by scanning the QR code below. This item is not a toy. Not for children under 3 years.



VoiceGift PLAY™ is a registered trademark of Voice Express Corp. ©2025 Voice Express Corp. All Rights Reserved.

Visit us online at [www.voice.gift](http://www.voice.gift)  
Send a message to [hi@voice.gift](mailto:hi@voice.gift)  
Follow us [@voicegift](https://www.instagram.com/voicegift)



Voice Express Corp.  
606 Post Road East  
Suite 3-706  
Westport, CT 06880

