



QUICK START GUIDE

For a full explanation of all features and instructions, please refer to the User's Guide (available for download from support.hubbleconnected.com).

1. Contents Inside Box

Models:

Skyvision AI Pro

Skyvision AI Pro Twin



Baby Unit *
(Camera Unit)



Parent Unit



Power Adapters *




Quick Start Guide




Base



Tube Connectors
x 2




Elbow Tube



Tubes



Cable Cover
x 4



Lid


Note: In multi-camera packs, you will find one or more additional Baby Units with power adapters.

WARNING:

Strangulation hazard. Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 feet away). Do not remove the tags from the AC Adapters. Only use the AC Adapters provided.

2. Setting up your Digital Video Baby Monitor

2.1 Connecting the Power Supply for the Baby Unit




- Insert the DC plug of the power adapter into the DC socket on the back of the Baby Unit.
- Connect the other end of the power adapter to a suitable electrical outlet.
- The baby unit turns on and the power indicator lights in Green colour.

Note

Only use the supplied power adapter (DC5V/1000mA).

2.2 Installing the camera mount on a wall


- Mark the position of the screw holes on the wall.
- Install wall anchors (Not provided) suitable for the wall type and mounting screws if needed.
- Fasten the mounting screws (Not provided) on the wall.
- Position the cable behind the base as shown in the picture before attaching the base on the wall.



2.3 Connecting the Power Supply of the Parent Unit.




- Connect the USB Type-C plug of the power adapter to the parent unit and the other end to the electrical outlet. Only use the enclosed adapter (5V DC / 1500mA).
- A rechargeable battery (Lithium-ion battery 2100mAh) inside the Parent Unit allows you to move it without losing the link and picture from the Baby Unit. We recommend charging for at least 4 hours before first use, and when the Parent Unit indicates the battery is low.
- Press and hold the POWER button on the top of the Parent Unit to turn it ON.



- Flip out the stand on the back of the Parent Unit and rotate it by 90 degrees to set up the desktop stand.


3. Overview of Parent Unit



4. Basic operation of the keys

Parent unit		
	Power button	Press and hold to switch the Parent Unit ON/OFF. Toggle once at standby mode to switch video on/off.
	Vol+ and Vol- buttons	Press -/+ to select volume level of the Parent Unit.
	Reset pin hole	Press and hold with a small pin to reset the unit.
Baby Unit		
	PAIR button	Press and hold to pair with the parent unit or for Hubble Wi-Fi® Setup. Located on the side of the camera.

5. Touch screen operation



Swipe up at the screen bottom to pop up the menu bar.

Swipe down at the screen bottom to hide the menu bar.

Scroll left/right on the menu bar to see all the options.

Menu Icons	
	Tap to access Hubble Baby entertaining games and videos.
	LCD Brightness Level Control (8 Levels).
	Zoom Level Control.
	Audio Media selection - Personal Recordings  , Lullabies/Soothing Sounds  , Audio Books  , Volume control of media playback  .
	Tap to turn flashlight on or off.
	Alarm Setting On status bar, indicates alarm set, and when flashing, that alarm time has been reached or missed.
	Tap to talk to Baby Unit.
	Tap to turn Night Light on or off.
	Camera Control (add + , del - , view  , scan ).
	Set Screen Off Timer (Off, 5 mins, 15 mins, 30 mins).
	Temperature scale select (°C/°F) Readings display in grey, but turns RED if > 29 °C / 84 °F or < 14 °C / 57 °F. Displays HH °C / °F if >36 °C / 97 °F. Displays LL °C / °F if < 1 °C / 34 °F.

Note: The feature is not available in this version when the icons appear grayed out.

* The playlist appears only if you make the audio recording via Hubble app.

Audio Media Playback menu icons	
	Tap to display personal recording* playlist.
	Tap to display soothing sound or lullaby playlist.
	Tap to display audio book playlist.
	Volume control of media playback.
	Play selected audio media on the playlist.
	Stop playing audio media.

6. Display icons

	Signal Level (5 Levels).
	Night Vision Mode (Video also changes to Black/White).
	Indicates the screen off timer is set.
	Volume Level Control (8 Levels).
	No Baby Unit detected.
	Battery Level Indicator (4 Levels).

7. Setting up the Camera Unit for Wi-Fi® internet viewing

7.1 Install HubbleClub by Hubble Connected App.



- Scan the QR code with your smart device and download HubbleClub by Hubble Connected App from the App Store for iOS devices or from the Google Play™ Store for Android™ devices.
- Install HubbleClub by Hubble Connected App on your device.

7.2 View on Compatible Smartphones and Tablets.



1. Open the HubbleClub by Hubble Connected App on your compatible smartphone or tablet.
2. Follow the in-app instructions to create your Hubble account and connect to your device.

Please take note of the following minimum system requirements:

Smartphones/Tablets: iOS 13.0, Android™ 8.0

Wi-Fi® requirements:

At least 1.5 Mbps dedicated upload bandwidth per Smart Monitoring Companion, test your Internet speed at: <http://www.speedtest.net/>

8. Installation of Crib mount

Ensure the finest viewing experience with the included crib mount featuring a cable management system. This mount is designed to attach directly to most crib top rails. Follow these instructions to assemble and install the crib mount.

8.1 Assembling the Crib Mount

8.1.1 Lower Tube Assembly

- Thread the power cord through the lower tube.
- Loosen the base nut and insert the lower tube's end into the base, ensuring it is fully seated.
- Tighten the base nut securely. Refer to Fig. 1 & Fig. 2 for guidance.



Fig. 1



Fig. 2

8.1.2 Connecting Tubes

- Thread the power cord through the connector and plug it into the lower tube until you hear a "Click" sound. Refer to Fig. 3 & Fig. 4.



Fig. 3



Fig. 4

8.1.3 Middle Tube Assembly

- Thread the power cord through the middle tube.
- Insert the middle tube into the lower tube connector until a "Click" sound confirms the connection. Refer to Fig. 5.
- Thread the power cord through the connector and insert it into the upper end of the middle tube, securing with a "Click" sound. Refer to Fig. 6.



Fig. 5



Fig. 6

8.1.4 Elbow Tube and Camera Tube

- Thread the power cord through the elbow tube.
- Insert the elbow tube into the upper tube connector until you hear a "Click" sound. Refer to Fig. 7.
- Thread the power cord through the camera tube with the power cord slot facing upward.
- Insert the camera tube into the connector, securing with a "Click" sound. Refer to Fig. 8 & Fig. 9.



Fig. 7



Fig. 8



Fig. 9

8.1.5 Locking the Lid

- Place the tab end into the lower open section of the elbow.
- Rotate the lid down into the elbow tube, pressing until you hear a "Click" to ensure a secure fit. Refer to Fig. 10 & Fig. 11.



Fig. 10



Fig. 11

8.1.6 Camera Locking

- Press the lock nut over the ball and attach the camera to it.
- Tighten the lock nut securely to hold the camera in place. Refer to Fig. 12 & Fig. 13.



Fig. 12



Fig. 13

8.1.7 Power Connection

- Insert the DC plug into the camera's power socket. Refer to Fig. 14 & Fig. 15.
- Any excess cable should be pushed back into the open slot.



Fig. 14



Fig. 15

8.2 Mounting the Crib Mount

- Place the crib mount base on the upper rail.
- Tighten the lock nut to securely mount the crib mount in a straight position. Refer to Fig. 16 & Fig. 17.



Fig. 16



Fig. 17

8.2.1 Powering On

- Insert the DC plug into the power socket at the bottom of the crib mount. Refer to Fig. 18.
- Connect the power adaptor to a suitable power outlet.



Fig. 18




Fig. 19

8.2.2 Cable Management Covers

- Determine the number of cable management sections are needed to cover the cable from the Crib Mount to below the bottom rail.
- Snap the needed sections together and insert the cable into the center of the cover.
- Peel the backing tape off the cable covers.
- Align the flat of the top sections with the bottom of the crib mount and press to rail to secure the sections. Refer to Fig. 19.

IMPORTANT SAFETY NOTES:

- **WARNING:** Choking Hazard - Contains Small Parts. Keep children under 5 away from the installation area.
- **WARNING:** Strangulation Hazard: The cable covers **MUST** be installed and be even with or extend below the bottom of the crib rails before use.

8.2.3 Setting Up Viewing:

- Power on the camera unit to view the crib image on the parent unit.
- Loosen the lock nut, adjust the camera unit, and choose the preferred zoom level on the parent unit (1x, 1.2x, 1.5x, or 2x).
- Tighten the lock nut securely to maintain the desired view. Refer to Fig. 20.



Fig. 20

WARNING - Choking Hazard:

May contain Small Parts. Parents must exercise caution and keep children under 5 away from the installation.

9. General Information

If your product is not working properly, read this Quick Start Guide or the online User's Guide of one of the models listed on page 1.

Contact Customer Service:

Live Chat: hubbleconnected.com

Email: support@hubbleconnected.com

Online warranty registration: <https://hubbleconnected.com/warranty>

Online Product Registration: <https://hubbleconnected.com/apps/product-registration>

Consumer Products and Accessories Limited Warranty ("Warranty")

Thank you for purchasing this Hubble Smart Nursery branded product manufactured by Hubble Baby (HK) Limited ("HUBBLE").

What Does this Limited Warranty Cover?

Subject to the items listed below in the section "What is not Covered" HUBBLE warrants that this Hubble connected branded product ("Product") will be free from defects in material and workmanship under normal use for a period of 1 year from the date of purchase and that any certified accessory ("Accessory") sold for use with this product will be free from defects in materials and workmanship under normal use for a period of 90-days from the date of purchase. This Limited Warranty is your exclusive warranty and is not transferable.

What is not covered?

This Limited Warranty excludes and does not cover:

- Normal deterioration or wear resulting from use;
- Damage caused by or resulting from misuse, abuse, or accident;
- Damage caused by or resulting from improper operation or storage;
- Damage caused by or resulting from contact with foreign substances, including, but not limited, to liquid, water, rain, humidity, perspiration, sand, dirt, and/or food;
- Damage caused by or resulting from the use of Non-Hubble Smart Nursery branded or certified Products or Accessories or other peripheral equipment;
- Damage caused by or resulting from modifications, alterations, tampering, improper installation, or repairs by someone other than Hubble connected or their authorized representatives;
- Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories; and,
- Periodic maintenance, repair and replacement of parts due to normal wear and tear.

What Other Limitations Are There?

THIS LIMITED WARRANTY SETS FORTH THE ENTIRE LIABILITY OF HUBBLE AND CONTAINS YOUR SOLE AND EXCLUSIVE REMEDY. OTHER THAN THIS LIMITED WARRANTY, HUBBLE MAKES NO ADDITIONAL REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IF YOUR STATE DOES NOT PERMIT THE DISCLAIMER OF WARRANTIES, THEN THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. REPAIR OR REPLACEMENT IS YOUR SOLE AND EXCLUSIVE REMEDY AGAINST HUBBLE AND Hubble Smart Nursery. IN NO EVENT SHALL HUBBLE OR Hubble Smart Nursery's LIABILITY TO REPAIR OR REPLACE YOUR PRODUCT OR ACCESSORY EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT AND ACCESSORY AND HUBBLE AND Hubble Smart Nursery's TOTAL LIABILITY FOR DAMAGES ARISING FROM THIS LIMITED WARRANTY SHALL NOT EXCEED THE PRICE YOU PAID FOR THE PRODUCT AND ACCESSORY REGARDLESS OF WHETHER SUCH CLAIM ARISES UNDER CONTRACT, STATUTE, TORT OR OTHERWISE. IN NO EVENT AND UNDER NO CIRCUMSTANCES WILL HUBBLE OR Hubble Smart Nursery BE LIABLE FOR DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR

CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES. ALL DISCLAIMERS, LIMITATIONS OF LIABILITY AND MODIFICATIONS OF WARRANTIES STILL APPLY EVEN IF THE LIMITED REMEDY OF REPAIR AND REPLACEMENT FAILS OF ITS ESSENTIAL PURPOSE.

Some jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This Limited Warranty gives you specific legal rights, and you may have other rights that vary from one jurisdiction to another.

Who is covered?

This Warranty extends only to the first consumer purchaser and is not transferable.

What will HUBBLE do?

HUBBLE or its authorized distributor at its sole discretion will, at no charge, repair or replace any Products or Accessories that do not conform to this Warranty. In the event that replacement is necessary to remedy a defect in material or workmanship, HUBBLE may use new or remanufactured products, accessories or parts of equal quality to the original Product or Accessory.

How to Obtain Warranty Service or Other Information?

To obtain service or information:

Live Chat: hubbleconnected.com

Email: support@hubbleconnected.com

Online warranty registration: <https://hubbleconnected.com/warranty>

Online Product Registration: <https://hubbleconnected.com/apps/product-registration>

You will receive instructions on how to ship the Products or Accessories at your expense and risk, to a HUBBLE Authorized Repair Center.

You must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date, place and seller of the Product; (c) if a warranty card was included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; and, (e) your name, address, email address and telephone number. These terms and conditions constitute the complete warranty agreement between you and HUBBLE regarding the Products or Accessories purchased by you, and supersede any prior agreement or representations, including representations made

in any literature publications or promotional materials issued by HUBBLE or representations made by any agent, employee or staff of HUBBLE, that may have been made in connection with your purchase of any Product and/or Accessory.

FCC and IC regulations (FCC Part 15)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules.
Industry Canada. This device complies with Industry Canada license-exempt RSS standard(s): Operation is subject to the following Two conditions:(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Download User Guide from website: support.hubbleconnected.com



Manufactured, distributed and sold by Hubble Baby (HK) Limited.
Apple logo is trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play and Android are trademarks of Google Inc. Wi-Fi is a trademark of the Wi-Fi Alliance. All rights reserved.

Printed in China
US_EN Version 5.0

