



Paper, perfected.

DPT-RP1

Digital Paper combines the simplicity of reading and writing on real paper with the convenience of digital features, including easy sharing across devices, searchable documents, and secure document encryption.



We envision Digital Paper being used by professionals and academics such as professors, researchers, PhDs, and graduate students within STEM fields. Other fields that we see taking advantage of what Digital Paper has to offer include business, legal, financial and medical professionals who read documents and take notes extensively.

Quick Tips

Download the Digital Paper App to your Mac or Windows PC:

The Digital Paper App is required to transfer documents:

<http://www.sony.net/dpapp>

Having issues downloading the Digital Paper App? Make sure that your anti-virus software isn't creating an issue:


The Digital Paper App will not install if a digital certification (CA) doesn't install, this can happen due to your firewall or if you are running anti-virus software.

Before you install the Digital Paper App, disable the firewall and anti-virus software on your computer. In addition, shut down all programs running. If you're using a Microsoft® Windows® computer, turn off all programs in the lower right-hand-corner System Tray.

1. Refer to your computer support or software provider for details on how to disable the firewall and anti-virus software.
 - a. For Webroot SecureAnywhere® anti-virus software, use the shut down protection option to stop all real-time protection and malware defense.
2. Enable your computer's firewall and anti-virus software after installing the Digital Paper App.

Trying to connect your Digital paper to your computer via Wi-Fi? Make sure the Digital Paper's Wi-Fi setting is turned on:

1. Press the (home) button on the Digital Paper, and tap [Settings].
2. Tap [Wi-Fi] to add a check mark.
3. Tap [Wi-Fi Settings] and then the SSID of the desired Wi-Fi network from the [Saved Network List].
 - a. If the Wi-Fi network that you want to connect to is not displayed, use the Digital Paper App to add the Wi-Fi network.
 - b. If you want to connect the Digital Paper to a computer while the device is in sleep mode, set [Keep Wi-Fi On During Sleep] to either [Always enabled] or [Enabled only when plugged in].
4. Connect the computer to the same network as the Digital Paper.
 - a. Communication is not possible if you connect the computer and the Digital Paper to different networks.



Make sure the stylus is fully charged:

For optimal performance, the stylus should be fully charged. You may experience slowness or lag during handwriting or annotations if it isn't sufficiently charged.

1. The pen may stop working if the battery level is low. Connect the pen to a computer (or an AC Adapter such as your smartphone charger) using the supplied USB cable to charge it. The charge indicator lights up in red while charging.
 - a. When connecting the USB cable, use caution not to press the tip of the pen. If the tip of the pen is pressed while connecting the USB cable, the pen operations will not work. In this case, disconnect and reconnect the USB cable.

There are two types of stylus tips:

Digital Paper comes with two types of tips for you to enjoy a smooth, natural writing experience. Designed specifically for use with the DPTA-RS1 Digital Paper Stylus, these tips come in two different materials—**gray** felt for pencil-like writing, or **black** polyoxymethylene (POM) for pen-like writing.

When you calibrate the stylus be precise as this can impact writing ability:

The pen may need to be calibrated if the actual writing or tapping is not aligned with the pen tip. Press the (home) button, and tap [Settings] – [System Settings] – [Pen Calibration].

Initialization and Setup video:

<https://youtu.be/kAMH8TWd3rE>

How to Connect to Bluetooth video:

<https://youtu.be/sAP5aJPXkzc>

For more tips and tricks on using the DPT-RP1, please visit:

<http://helpguide.sony.net/dpt/rp1/v1/en/index.html>