




GAS RANGE

MODELS:

WFGS7530RV1 (Black Stainless)

WFGS7530RZ1 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	11	7101P485-60	Screw, Anti-Tip Kit	24	W11623712	Hinge, Spacer
	W11642081	Owner's Manual	12	W11672010	Grate, Bumper	25	W10530626	Screw
	W11639170	Tech Sheet	13	W11637551	Spring, Clip			FOLLOWING PARTS NOT ILLUSTRATED
	W11641568	Quick Start Guide	14	W11736687	Bracket, Front Cooktop		W11334462	Harness, Main
2		Burner Cap Kit	15		Frame, Cooktop		W11454086	Harness, Bake
	W11498499	Black (Set of 4)		W11367962	Black		W11334489	Harness, Cooktop
3	W11600788	Burner Kit (Set of 4)	16	9780274	Screw		3196520	Clip, Wire
4		Cooktop	17	W11366598	Bracket, Spark Module		313438	Clip, Harness
	W11279795	Black	18	W11352193	Flame Spreader (Left Front and Right Front)		3196896	Clip, Wire
5		Panel, Manifold		W11352195	Flame Spreader (Left Rear)			
	W11393101	Black Stainless		W11352197	Flame Spreader (Right Rear)			
	W11393100	Stainless	19	W11635774	Oval Flame Spreader Kit			
6		Knob, Control			(Center)			
	W11632049	Black Stainless	20	8016P022-60	Glide, Main Top			
	W11632045	Stainless	21		Hinge, Grate			
7		Grate Kit		W11621636	Black			
	W11622335	Black (Set of 2)	22	W11640437	Griddle, Cooktop			
8	W10673618	Screw	23		Bezel			
9		Panel, Manifold End Cap		W11632249	Black Stainless			
	W11361197	Black Stainless (Left)		W11632247	Stainless			
	W11361196	Black Stainless (Right)						
	W11386024	Stainless (Left)						
	W11386023	Stainless (Right)						
10	W11379945	Bracket, Anti-Tip						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W11400084	User Interface Assembly	8	3196169	Screw
	W11625423	Black (Left)				9	W11350452	Spark Module
	W11625420	Black (Right)	5	W10818365	Module, Spark DSI	10	W11393669	Cover, Upper Rear
2	W11736649	Shield, Heat	6	3196160	Screw	11	3196178	Screw
3		Panel, Control	7		Panel, Lower			
	W11371989	Black Stainless		W11299317	Black Stainless			
	W11371988	Stainless		W11625438	Stainless			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11402213	Screw	6	W11450459	Electrode, Bake	18	3196265	Screw
2	W10827923	Electrode, Spring	7	W11279816	Manifold Assembly	19	W10849722	Orifice (18K) (Left Front, Right Front and Center)
3	W11300870	Orifice Holder Assembly (18K) (Left Front) (Includes Orifice)	8	W11279839	Valve, Single (Left Front, Right Front)			Orifice, Not Serviced
	W11300871	Orifice Holder Assembly (10K) (Left Rear) (Includes Orifice)		W11279838	Valve, Single (Left Rear)		W10849719	Orifice (5K) (Right Rear) Orifice, Not Serviced
	W11300879	Orifice Holder Assembly (18K) (Right Front) (Includes Orifice)		W11279837	Valve, Single (Right Rear)		W10907868	Orifice (10K) (Left Rear) Orifice, Not Serviced
	W11300867	Orifice Holder Assembly (5K) (Right Rear) (Includes Orifice)	9	W10224921	Bracket, Aegis			FOLLOWING PARTS NOT ILLUSTRATED
	W11634398	Orifice Holder Assembly (12K) (Center) (Includes Orifice)	10	3196385	Screw		W11370714	LP Conversion Kit
4	W11384792	Tubing (Manifold to Regulator)	11	3400016	Screw		W10838304	Orifice, LP Bake
5	W11637977	Harness, Igniter (Includes Switches)	12	W10714060	Element, Broiler		W11402210	Tie, Wire
			13	W10184491	Spreader, Flame (Oven)			
			14	9758078	Burner, Bake			
			15	W10818355	Regulator			
			16	W11428831	Electrode (Left Front, Left Rear)			
				W11428858	Electrode (Right Front, Right Rear)			
				W11581944	Electrode (Center)			
			17	W10362924	Screw			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11366110	Box, Flue	19	3400080	Screw	36	W11644425	Fan, Convection
2	W11279866	Shield, Flue	20	W11734475	Control, Electronic	37	W11464547	Bracket, Front Frame
3	W10067840	Screw	21	W11491751	Seal, Door	38	W11373155	Cover, Conv Fan
4		Panel, Side	22	W10435470	Brace, Main Back	39	W10516115	Screw
	W11445467	Black	23	W11379353	Retainer, Insulation (Left)	40	W10379120	Screw
5	W10137382	Clip, Panel		W11379943	Retainer, Insulation (Right)	41	W11625914	Ventilation Assembly, Console
6	W11287215	Bracket, Cooktop Console	24	3196560	Screw	42	3400701	Screw
7	W10362924	Screw	25	W11661976	Cord, Power	43	W11411632	Blower, Tube
8	3196560	Screw	26	W10289077	Receiver, Hinge	44	W11642475	Tube, Clamp
9	W10341186	Front Foot Assembly	27	W11511828	Switch, Door	45	W11365827	Bracket, Acu
10	W10058460	Foot, Leveling	28	W11634772	Light Assembly	46	W11596199	Cover, Side Fan
11	W11602073	Bottom, Oven	29	W10571723	Bulb, Halogen 40 Watts	47	W11607819	Rack, Oven (Gull-Wing)
12	W11633068	Sensor	30	9761013	Front Door Latch Assembly	48	8016P022-60	Glide, Main Top
13	8053967	Baffle, Burner Oven	31	W10078370	Rod, Push Latch	49	W11661815	Basket, Airfry
14	8053969	Shield, Heat	32	W10107820	Rear Door Latch Assembly	FOLLOWING PARTS NOT ILLUSTRATED		
15	W11640074	Shield, Lower	33	W10674705	Glide, Drawer Front			
16	W10390008	Base Rail Assembly (Left)	34	3196178	Screw	W10818362	Insulation, Wrap	
	W10390007	Base Rail Assembly (Right)	35	W11173792	Rack, Oven	W11407376	Insulation, Back	
17	9757239	Rod, Door Switch						
18	W10031780	Screw						

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11353056	Black Stainless
	W11353054	Stainless
2	W10465158	Screw
3		Door, Lower Trim
	W11444043	Black
4	9761344	Liner, Door
5	W10031790	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	9758162	Glass, Inner
7	W10316950	Frame, Glass
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10388635	Hinge, Door (Active)
11		Glass, Outer Door
	W11729636	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Trim, Door
	W10746436	Black (Left)
	W10746435	Black (Right)
13	W10327235	Screw
14	W11379944	Strap, Door
15	W10440013	Hinge, Door (Active)
16	W10884775	Badge
17	W10200660	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10674708	Glide, Drawer Rear	4		Panel, Drawer Front
2	W10688022	Drawer, Storage		W11450003	Black Stainless
3	W10462909	Bracket, Mounting		W11190210	Stainless
			5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		PAINT, TOUCH-UP (1/2oz.)
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	285006	Black
	350930	White
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORY PARTS
	30-48KITRC	Gas Range Connector Kit
	4396096RB	Griddle
	4396923	Broiler Pan and Grid