


INSIGNIA™

No Tool Assembly TV Stand

NS-HF2001



Before using your new product, please read these instructions to prevent any damage.

Contents

Introduction	2
IMPORTANT SAFETY INSTRUCTIONS	2
Features	3
Dimensions	3
Package contents	4
Parts	4
Hardware	4
Assembly instructions	5
STEP 1 - Fasten a metal frame to the top shelf	5
STEP 2 - Fasten the other shelves to the metal frame	6
STEP 3 - Attach the other metal frame	7
STEP 4 - Attach the warning label	8
ONE-YEAR LIMITED WARRANTY	9

Introduction

Congratulations on your purchase of a high-quality Insignia product. Your NS-HF2001 represents the state of the art in TV stand design and is designed for reliable and trouble-free performance.

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

Use of a TV that is too heavy or large is hazardous. A TV that is too heavy will create a risk of a tip-over that can cause severe injury or death. A TV that is too large for the available space might be accidentally pushed or bumped off the furniture, or subject to tip-over.

- Check the size and weight of your TV. See Dimensions on page 3 before you begin assembly!
- Your TV stand is designed for use with televisions weighing 50 lbs. (22.7 kg) or less. Never use with a TV that weighs more.
- The size of the television, front-to-back and side-to-side, must fit within the space shown in Dimensions on page 3.
- Never place the front edge of the TV past the front edge of the TV support shelf (or stop molding – if equipped).
- Never allow the sides of the TV to extend more than one inch past the side edges of the TV support surface.
- If the TV has a CRT picture tube, the picture tube cone may extend past the rear of the support shelf.
- Be sure to apply the warning label as instructed in the last assembly step. The label provides important safety related information.

WARNING: Please use your furniture correctly and safely. Improper use can cause safety hazards, or damage to your furniture or household items. Carefully read the following safety information.

Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result may tip over onto the child.

- NEVER allow children to climb or play with the TV or furnishing supporting the TV.
- NEVER place toys, food, remote, etc. on top of the TV or TV furnishing.
- ALWAYS use either the safety hardware as instructed or other wall anchoring device.

Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to furniture collapse or over turning onto a child.

- NEVER place a TV on furniture that is not intended to support a TV.
- NEVER exceed the maximum size and weight of the TV shown in the instructions.
- Be sure to apply the TV warning label as shown in the instructions.
- Overloading drawers and shelves may result in furniture that can break or sag, or tip-over which may result in injury.
- NEVER exceed the weight limits shown in the instructions.
- Place the heavier items on lower shelves as far back from the front as possible.
- Load the bottom surfaces first to avoid top-heavy furniture.


- Moving furniture that is not designed to be moved or equipped with casters may result in injury or damage to furnishings or personal property.
- ALWAYS unload shelves and drawers, starting with the top surfaces, before moving.
- NEVER push or pull furniture on carpet. Have a friend help lift properly to move and/or reposition it.

SAVE THESE INSTRUCTIONS

Features

- Holds up to a 50-inch TV weighing up to 50 lbs. (22.7 kg)
- Assembles easily with no tools
- Two large shelves for a wide range of components
- Dark wood finish blends into nearly all rooms

Dimensions



Cleaning your stand


CAUTION: Never use chemical cleaners or wood care products to clean your stand. They may damage the surface.

- Use standard dry dusters or cloths. If there are fingerprints or other hard to remove debris, scrub them with a damp cloth, then immediately wipe away any water with a dry cloth.


Package contents

Make sure that you have all of the parts and hardware necessary to assemble your new TV stand.

Parts




C Shelf (3)



D Metal frame (2)

Hardware

LABEL	HARDWARE	QTY.
1	 Fastener	12


LABEL	HARDWARE	QTY.
2	<div style="border: 1px solid black; padding: 5px;"> <p>⚠ WARNING • ADVERTENCIA • AVERTISSEMENT ⚠</p> <p>Never use this furniture with a TV that is too large or too heavy. Severe injury or death can occur. The TV and furniture will be unstable and may tip.</p> <p>• The TV must weigh less than 50 lbs.</p> <p>• The base of the TV must be able to sit completely on this stand.</p> <p>Refer to instruction book for complete safety information.</p> <p><i>Note:</i> This is a permanently label. Do not try to remove. Surface will be damaged.</p> <p>Nunca use este mueble con un televisor que sea demasiado grande o demasiado pesado. Podría resultar en una lesión grave hasta la muerte. El televisor y el mueble estarán inestables y pueden volcarse.</p> <p>• El televisor debe pesar 22.68 kg como máximo.</p> <p>• La base del televisor debe poder colocarse completamente sobre este estante.</p> <p>Consulte el folleto de instrucciones para información completa sobre la seguridad.</p> <p><i>Nota:</i> Esta etiqueta es permanente. No intente quitarla. Causará daño a la superficie.</p> <p>Né jamais utiliser ce meuble avec un téléviseur qui soit trop large ou trop lourd. Risque de provoquer des blessures graves, voire mortelles. Le téléviseur et le meuble seront instables et risquent de se renverser.</p> <p>• Le téléviseur doit peser 22.68 kg comme maximum.</p> <p>• La base du téléviseur doit pouvoir être placée complètement sur cette tablette.</p> <p>Consulter le manuel d'instructions pour information complète concernant la sécurité.</p> <p><i>Remarque:</i> Cette étiquette est permanente. Ne pas essayer de la retirer. Causera des dommages à la surface.</p> </div> <p>TV warning label</p>	1

Assembly instructions


STEP 1 - Fasten a metal frame to the top shelf.

CAUTION: Assemble your TV stand on carpeting or the empty carton to avoid scratching your stand.


You'll need



C Shelf (1)



D Metal frame (1)





1 Fasteners (2)

- 1 With the screw holes facing up, align one of the shelves (**C**) with the holes on the short end of one of metal frames (**D**).
- 2 Insert two fasteners (**1**) through the metal frame and into the shelf. Tighten the fasteners.


CAUTION: Do not use tools, such as a wrench, to tighten the fasteners. Tighten only by hand until the fasteners stop turning.

The legs are on this end. They extend farther from the crossbar than the ends that attach to the top shelf.



STEP 2 - Fasten the other shelves to the metal frame.**You'll need**


C Shelf (2)





1 Fasteners (4)

- 1 Lay your TV stand on its back edges.
- 2 Align the other two shelves (C) with the holes in the metal frame (D).
- 3 Insert two fasteners (1) through the metal frame and into each shelf. Tighten the fasteners.


CAUTION: Do not use tools, such as a wrench, to tighten the fasteners. Tighten only by hand until the fasteners stop turning.



STEP 3 - Attach the other metal frame.**You'll need****D** Metal frame (1)**1** Fasteners (6)

- 1 Align the other metal frame (**D**) with the three shelves, then insert two fasteners (**1**) per shelf through the metal frame and into the shelves.
- 2 Tighten the fasteners.

CAUTION: Do not use tools, such as a wrench, to tighten the fasteners. Tighten only by hand until the fasteners stop turning.



STEP 4 - Attach the warning label.


You'll need



2 Warning label (1)

- 1 Carefully stand your TV stand upright.
- 2 If you plan to put a TV on your stand, apply the WARNING LABEL (2) to the top shelf . You should be able to read the label when you remove the TV from your stand. When you put the TV on your stand, it should hide the label.
- 3 Peel off the backing and apply the label.

CAUTION: This is a permanent label intended to last for the life of your TV stand. After you apply it, do not try to remove it. You may damage the surface of your stand.



You're done! Clean your TV stand with a damp cloth, then wipe it dry.

ONE-YEAR LIMITED WARRANTY

Definitions:

The Distributor* of Insignia branded products warrants to you, the original purchaser of this new Insignia-branded product ("Product"), that the Product shall be free of defects in the original manufacturer of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period").

For this warranty to apply, your Product must be purchased in the United States or Canada from a Best Buy branded retail store or online at www.bestbuy.com or www.bestbuy.ca, and is packaged with this warranty statement.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. Your purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a Best Buy retail store location, please take your original receipt and the Product to any Best Buy store. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging. If you purchased the Product from a Best Buy online web site (www.bestbuy.com or www.bestbuy.ca), mail your original receipt and the Product to the address listed on the web site. Make sure that you put the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

To obtain warranty service, in the United States call 1-888-BESTBUY, Canada call 1-866-BESTBUY. Call agents may diagnose and correct the issue over the phone.

Where is the warranty valid?

This warranty is valid only in the United States and Canada at Best Buy branded retail stores or websites to the original purchaser of the product in the country where the original purchase was made.

What does the warranty not cover?

This warranty does not cover:

- Food loss/spoilage due to failure of refrigerator or freezer
- Customer instruction/education
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to weather, lightning, and other acts of God, such as power surges
- Accidental damage
- Misuse
- Abuse
- Negligence
- Commercial purposes/use, including but not limited to use in a place of business or in communal areas of a multiple dwelling condominium or apartment complex, or otherwise used in a place of other than a private home.
- Modification of any part of the Product, including the antenna
- Display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage or power supply
- Attempted repair by any person not authorized by Insignia to service the Product
- Products sold "as is" or "with all faults"
- Consumables, including but not limited to batteries (i.e. AA, AAA, C etc.)
- Products where the factory applied serial number has been altered or removed
- Loss or Theft of this product or any part of the product
- Display panels containing up to three (3) pixel failures (dots that are dark or incorrectly illuminated) grouped in an area smaller than one tenth (1/10) of the display size or up to five (5) pixel failures throughout the display. (Pixel based displays may contain a limited number of pixels that may not function normally.)
- Failures or Damage caused by any contact including but not limited to liquids, gels or pastes.

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Insignia:

For customer service please call 1-877-467-4289

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2019 Best Buy. All rights reserved.

Made in China

INSIGNIA™

For product inquiries, please contact us with the information below:

1-877-467-4289

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2019 Best Buy. All rights reserved.

Made in China

V1 ENGLISH
19-0457