

**WM-SW2N1****Cuisinart® Sandwich Maker**

The Cuisinart® Sandwich Maker does more than lunch. This versatile Cuisinart product also makes omelets and French toast! Designed to cook two servings at a time, it is perfect for breakfast, lunch, or light dinners. Dual indicator lights ensure nothing over- or under-cooks, and nonstick plates makes cleanup easy. A lock-down lid guarantees both sides cook evenly, and raised ridges on plates seal in ingredients. When the work is done, the lid lock and cord wrap make storage easy.

- Cooks 2 sandwiches, omelets or servings of French toast
- Lock-down lid positions with food on plates to evenly brown both sides
- Ready-to-Cook and Ready-to-Eat indicator lights
- Raised ridges in cooking plates seal edges of bread or omelets to keep ingredients inside and divide sandwiches
- Updated plate design to reduce overflow
- Nonstick baking plates wipe clean in seconds
- Cord storage

**SPECIFICATIONS**

---

**ITEM**

Dimensions: 9.07"(L) x 8.87"(W) x 3.57"(H)  
Weight: 2.87 lbs

**UNIT CARTON**

UPC: 086279175229  
Dimensions: 9.92"(L) x 4.57"(W) x 10.35"(H)  
Weight: 3.64 lb.  
Cubic Ft: 0.27

**MASTER CARTON**

Master Pack: 2  
MBC: 10086279175226  
Dimensions : 10.79"(L) x 10.08"(W) x 11.61"(H)  
Weight: 8.05 lb.  
Cubic Ft: 0.73

---

