

### PACKAGE CONTENTS

- MHL adapter
- Samsung adapter
- Micro USB power adapter
- *Quick Setup Guide*

### FEATURES

- Supports 1080p HD and 4K x 2K resolution (2160p30) HD video and 7.1/5.1 digital audio surround sound playback (MHL 3 Enabled)
- Connects from the micro-USB port on your MHL™-enabled phone or tablet to an HDMI® input on a TV, projector, or monitor (requires an HDMI® cable, not included)
- Control your smart phone content with your TV remote
- Simultaneously charge your phone while you are using it to send audio and video to your HDTV
- Includes adapter for Samsung MHL-enabled devices (works with Galaxy S® III, 4, 5; Galaxy Note® II, 3, 4, Edge; and other Samsung products)

### COMPATIBILITY

- Your smartphone or tablet needs to be MHL compatible. Check with your device's documentation or with the manufacturer to determine if it's MHL enabled.


### USING YOUR MHL ADAPTER

- 1 Connect the included micro USB power adapter to the micro USB jack on the MHL adapter and then into a power outlet.
- 2 Connect one end of your HDMI cable (not included) to the adapter and the other to an available HDMI input jack on your TV.

- 3 Connect the micro USB connector of the adapter to an MHL-enabled smart phone or tablet.

**Important Note:** Most Samsung MHL-enabled devices require the included Samsung adapter to be connected to the USB/MHL connector on the Samsung device. The micro USB connector on the MHL cable then connects to the Samsung adapter.

- 4 Turn on your smart phone or tablet.
- 5 Turn on your TV, then switch the input/source to the HDMI input/source that matches the HDMI input jack you connected the adapter to on your TV (HDMI1, HDMI2, etc.). Content from your smart phone or tablet is displayed on the TV.



USING YOUR TV REMOTE  
CONTROL TO CONTROL YOUR  
MHL DEVICE (phone, tablet, or  
other device)

You can control the playback of the content on your device with your TV's remote control.

Here are the things you need to consider:

- This feature should automatically be enabled when you connect your smartphone or tablet to your TV, but you may have to enable it through your TV's settings menus. Because MHL uses a TV's HDMI CEC feature, look for the CEC Enable setting on your TV's settings menu.
- Certain buttons on your TV's remote control can be used to control audio and video file playback from your MHL-enabled device. These buttons may include **PLAY, PAUSE, NEXT TRACK/FORWARD, PREVIOUS TRACK/REVERSE**, and **STOP**.
- Buttons that control menu navigation on your TV may also be used to navigate some functions or apps running on your MHL-enabled device. These buttons include **UP, DOWN, RIGHT, LEFT**, and **ENTER** or **OK**.
- Not all buttons are supported by all devices or all apps. It depends on the device and app you are using.

LEGAL NOTICES

FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any

interference received, including interference that may cause undesired operation.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ICES-003

This Class B digital apparatus complies with Canadian ICES-003; Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

TROUBLESHOOTING

PROBLEM	SOLUTION
No sound or picture	<ul style="list-style-type: none"><li>• Make sure that all your connections are correct and secure.</li><li>• Make sure that you have connected the micro USB power adapter to a wall outlet.</li><li>• Make sure that you have selected the correct HDMI input/source on your TV.</li><li>• Make sure your phone or tablet supports MHL. Check with your phone or tablet's manufacturer.</li><li>• If you have a Samsung device, try connecting using the included Samsung adapter.</li><li>• Try connecting without the included Samsung adapter.</li></ul>
My phone or tablet keeps disconnecting	<ul style="list-style-type: none"><li>• Make sure that all your connections are correct and secure.</li><li>• Make sure that you have connected the micro USB power adapter to a wall outlet.</li></ul>
My phone or tablet is not charging	<ul style="list-style-type: none"><li>• Make sure that you have connected the micro USB power adapter to a wall outlet.</li><li>• If you have a Samsung device, try connecting using the included Samsung adapter.</li><li>• Try connecting without the included Samsung adapter</li></ul>

ONE-YEAR LIMITED  
WARRANTY

Visit [www.rocketfishproducts.com](http://www.rocketfishproducts.com) for details.

CONTACT ROCKETFISH:

For customer service, call  
1-800-620-2790 (U.S. and Canada) or  
01-800-926-3010 (Mexico)  
[www.rocketfishproducts.com](http://www.rocketfishproducts.com)

MHL and the MHL Logo are trademarks or registered trademarks of MHL, LLC in the United States and other countries.

ROCKETFISH is a trademark of Best Buy and its affiliated companies.  
Distributed by Best Buy Purchasing, LLC  
©2015 Best Buy. All rights reserved.  
**Made in China**