



TIPS:

Your suggestions and comments for Costway are really important to us!
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2018

Great product so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, Costway will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!



COSTWAY

WHERE THERE IS COSTWAY THERE IS HOME



USER'S MANUAL

Christmas Wreath

CM22821

GB

ARTIFICIAL CHRISTMAS WREATH
READ CAREFULLY, KEEP FOR FURTHER REFERENCE

Article of decoration
For indoor use only
All the diagrams are given for illustrative purposes only. There may be variations from one model to another.



Content :

Reference*	Width	Number of wreath parts
CM22821	4FT	2

* The reference number is indicated on the carton above the gencod.
No tools are required for the assembly.

Before beginning

Check whether all parts have been delivered.
Save the carton box for storing your tree.

NO	A	B
PART LIST		
DESCRIPTION	HALF OF WREATH	SCREWS AND NUTS
QTY/PC	2PCS	4PCS

Assembly instructions

1-Take the two parts of wreath out of the box and fasten the four screws and nuts.



2-Gently grasp the branch tips and spread them out away from the center.

3-Pressing the ON/OFF button once will turn on the lights and begin the timer.
The timer will run continually: 6 hours with lights on, then 18 hours with lights off and repeat until deactivated by pressing ON/OFF button.

Disassembly and storage

Remove all decorations.

Disassemble the wreath in reverse order of the assembly.

For a better conservation, store the wreath in its carton box in a cool dry place. Do not store when humid.

Caution

To be assembled by or under supervision of an adult.

Keep plastic bags out of reach of young children.

Keep away from fire or hot temperature. Do not light a candle on or near the wreath. Do not leave lighted lighting chains unattended.

Do not overload the wreath with heavy and/or too numerous decorations.

Place the wreath on a plane surface in order to ensure its stability.

This wreath is intended for indoor use only.

Keep an eye on young children.

Keep those information for future reference.

Made in China