

INSTRUCTIONS FOR USE

THE LOCK IS PRE SET TO 0-0-0

PUSH THE BUTTON 1. IN THE DIRECTION OF THE ARROW
WHILE IN THIS POSITION SET EACH NUMBER TO
YOUR SELECTION

RELEASE THE BUTTON AND YOUR NUMBER IS NOW SET
TAKE CARE WHEN SETTING THE NUMBERS NOT TO
RELEASE THE BUTTON:

