HOLD THE LEVEL TO THE TOP EDGE OF THIS TEMPLATE

Drill a hole here



INSIGNIA™

Wall mount template

If possible, position one of the mounting holes onto a stud behind dry wall. Use a wall anchor if you are not mounting to a stud.

Warning: Improper installation can result in serious injury or damage to your soundbar.
If necessary, seek the assistance of a professional.



1. Determine where you would like to mount the soundbar. The center line of the template should match the center of the TV.
Note: If you are mounting to drywall, use a stuffinder to locate studs. A wall anchor is not needed if you are attaching to a stud.

2. Hold this template in the location you want, and use a level to level it, then tape it to the wall.

Drill two holes at the indicated points.

3. Remove the template from the wall. You must use suitable wall anchors (not supplied) if you cannot mount the soundbar to available wall studs.



4. Fasten two screws (not supplied) to the wall. The screw heads should protrude from the wall approximately 1/4 in. (6 to 8 mm). The screw width must be about 3/16 in. and the screw head about .3 in. (7.6 mm) to 3/8 in. (9.5 mm).



5. Align the speaker hanging brackets with the screws, then hang the soundbar on the screws.



Drill a hole here



Center Line

Scale: 1:1