SNOWTIDE HELMET RS1

OVERVIEW

- Vent Switch
- Goggle Rest
- Air Vents
- Anti-fogging Vents
- "+" Button
- Charging Port
- "-" Button
- PTT Button (Push-to-Talk)
- Power Button
- MIC
- Strap Holder
- Holder Hook
- Size Dial

Scan to download the Snowtide app.

## POWER ON / OFF

Press and hold for ~3 sec.

"Power On" or "Power Off"

Listen for the voice prompt.

ON   **OFF**

Wait for the light to turn on/off.

BLUETOOTH PAIRING

Make an account via the Swagtron Snowtide app, then turn Bluetooth on.

Power on your helmet.

Follow in-app instructions to complete connection.

Android: Tap "click to connect" to begin pairing. The devices should now pair automatically.

iOS: Tap "click to connect" to begin pairing. The helmet will automatically connect for communications. From the in-app pop-up, open settings then open the Bluetooth menu. Tap "Helmetphone-RS" to connect for audio and finish pairing. The devices should now be connected.

Note: Phone answering, intercom (push-to-talk), locator alarm, and SOS alert functions are available after successfully connecting to the app.
For easier identification, it is recommended to rename your helmet after connecting.

USING THE INTERCOM

Using Push-to-Talk (PTT)

To use PTT, follow the in-app instructions and create a group. A group will be created with a 6-digit code.

To connect to an existing group, tap "join group" in-app and type in the 6-digit number received via invitation and/or from the group's creator.

Press and hold the helmet's PTT button (or the speaker icon in-app) to talk. Make sure to continue holding until you are finished talking, then release.

Note: The helmet should beep each time you press or release the PTT button. Additionally, a warning tone will emit if you hold the PTT button longer than 1 min.

PLAYING MUSIC

Note: To listen to music with your helmet, use your phone's Bluetooth menu to connect to "Helmetphone-RS".

Starting/Stopping Songs

Press to play/pause.

Adjusting Volume

Press to increase or decrease volume.

Note: If volume is increased to the max, a voice prompt will confirm.

LOCATOR ALARM

When the distance between your phone and the helmet exceeds 49 feet (~15 meters), the app and helmet will sound an alarm simultaneously.
Note: Large obstacles such as buildings may cause distance detection errors if positioned between the phone and the helmet.

SOS ALERT

1. Set your emergency contacts in the Swagtron Snowtide App.
2. When using the app, the SOS alert will automatically turn on and notify your emergency contact in the event of an accident.

IMPORTANT NOTES

- In general, only one feature can be used at a time. E.g., PTT cannot be used during phone calls.
- When you use PTT, music will pause. Once PTT ends, music will resume automatically.
- When you receive a phone call, music will pause. Once the call ends, music will resume automatically.

HANDLING CALLS

Note: To handle calls with your helmet, use your phone's Bluetooth menu to connect to "Helmetphone-RS".

Press any of the 3 buttons to accept an incoming call. When you're finished with the call, press again to hang up.

Press and hold any of the 3 buttons for ~1.3 sec to decline an incoming call.

FITTING / ADJUSTING

For maximum protection and comfort, make sure your helmet fits properly. It should sit firmly without pressing or chafing. It should not ride up your forehead or cover your eyes in any way.

- The helmet should fit comfortably and stay on when you move your head forward and backward as well as side-to-side. Use the dial as needed.
- The ear pads and inner padding should exert firm, even pressure on all sides of your head without being tight or uncomfortable.
- When you are satisfied with the fit, tighten the chinstrap so it fits snugly and the buckle locks. If your straps aren't adjusted right, your helmet won't stay on properly. The loose end of the strap must loop back up through the rubber O ring.
- To adjust the position of the straps, hold one end of the chin buckle in one hand and slide the adjuster up or down the strap as necessary, to create a balanced and even Y shape underneath your ears. Position the buckle away from your jawbone. It should not be possible to remove the helmet without opening the chin strap. If it is possible, adjust the helmet.

CHARGING

Connect the charging cable to the port. The power button will blink during charging and turn off when charging is completed.

Note: The helmet automatically turns off when charging.